# CURSOR TIER 3 SERIES

Industrial application

C87 C87 ENT X - CURSOR 87 TE X

**Technical and Repair manual** 

This publication provides unit and relevant component repair data, specifications, instructions and methodologies.

This publication has been drawn up for qualified and specialised personnel.

Before performing any operation check that the part relevant to the unit on which you must work is available along with all safety devices for accident-prevention, such as, goggles, helmet, gloves, shoes, etc. and hoisting and transporting equipment.

Operations are to be performed by following the indications included here, using the special equipment indicated and assuring proper repair, compliance with schedule and operator's safety requirements.

Each repair must aim to restore operating efficiency and safety in compliance with the FPT provisions.

FPT cannot be held liable for modifications, alterations or other interventions non authorised by FPT on the vehicle and if the unit is warranted the above mentioned interventions will cause its expiration.

FPT is not liable for repairing interventions.

FPT will provide further details required to carry out the interventions and all the instructions that are not included on this publication.

Data included in this publication may not be up-to-date therefore subject to Manufacturer's modifications that can be added at any time for technical or commercial purposes and also to meet new law regulations in other Countries.

If issues on this publication differ from what is actually noticed on the unit, please get in touch with the FPT network before starting any intervention".

It is forbidden to copy this text or any of its parts and all illustrations included.

Publication edited by FIAT Powerrtrain Technologies Mkt. Advertising & Promotion Viale dell'Industria, 15/17 20010 Pregnana Milanese Milano (Italy) Print **P2D32C006E** - 2<sup>nd</sup> Ed. 06.2007 Produced by:



B.U. TECHNICAL PUBLISHING Iveco Technical Publications Lungo Stura Lazio, 15/19 10156 Turin - Italy

	٠	

с го		Dout
Cursor F2		Fart
Cursor en	ngines application G-Drive	Part

	Page
PREFACE TO USER'S GUIDELINE	
SYMBOLS	
🗋 Warnings	
Service operations	
GENERAL WARNINGS	ļ
GENERAL WARNINGS ON THE ELECTRIC SYSTEM	
Bonding and screening	
OPTIONAL ELECTRICAL AND MECHANICAL PART	⁻S
CONVERSIONS BETWEEN THE MAIN UNITS OF MEASUREMENT OF THE INTERNATIONAL SYSTEM AND MOST USED DERIVED QUANTITIES	
KEY OF LECTURE OF THE HEADINGS	

# PREFACE

Manuals for repairs are split into Parts and Sections, each one of which is marked by a numeral; the contents of these sections are indicated in the general table of contents.

The sections dealing with things mechanic introduce the specifications, tightening torque values, tool lists, assembly detaching/reattaching operations, bench overhauling operations, diagnosis procedures and maintenance schedules.

The sections (or parts) of the electric/electronic system include the descriptions of the electric network and the assembly's electronic systems, wiring diagrams, electric features of components, component coding and the diagnosis procedures for the control units peculiar to the electric system.

Section 1 describes the engines illustrating its features and working in general.

Section 2 describes the type of fuel feed.

Section 3 relates to the specific duty and is divided in four separate parts:

I. Mechanical part, related to the engine overhaul, limited to those components with different characteristics based on the relating specific duty.

2. Electrical part, concerning wiring harness, electrical and electronic equipment with different characteristics based on the relating specific duty.

3. Maintenance planning and specific overhaul.

4. Troubleshooting part dedicated to the operators who, being entitled to provide technical assistance, shall have simple and direct instructions to identify the cause of the major inconveniences.

Sections 4 and 5 illustrate the overhaul operations of the engine overhaul on stand and the necessary equipment to execute such operations.

The appendix contains a list of the general safety regulations to be respected by all installation and maintenance engineers in order to prevent serious accidents taking place.

The manual uses proper symbols in its descriptions; the purpose of these symbols is to classify contained information. In particular, there have been defined a set of symbols to classify warnings and a set for assistance operations.

# **SYMBOLS - Warnings**



#### Danger for persons

Missing or incomplete observance of these prescriptions can cause serious danger for persons' safety.



#### Danger of serious damage for the assembly

Failure to comply, both fully or in part, with such prescriptions will involve serious damage to the assembly and may sometimes cause the warranty to become null and void.



#### General danger

It includes the dangers of above described signals.



#### Environment protection

Moreover, it describes the correct actions to be taken to ensure that the assembly is used in such a way so as to protect the environment as much as possible.



### Service operations

Example



 $\emptyset$  | = Seat of small end bush

 $\emptyset$  2 = Seat of connecting rod bearings.



Close applying the required torque Close applying the required torque + angular value

	Removal Disconnection	-		Intake
	Refitting Connection			Exhaust
==	Removal Disassembly	_	$\langle \neg \rangle$	Operation
	Fitting in place Assembly	-	Q	Compression ratio
	Tighten to torque	-		Tolerance Weight difference
$\widehat{\bigcirc}_a$	Tighten to torque + angle value	-		Rolling torque
•	Press or caulk	-		Rotation
846	Regulation Adjustment	-	$\triangleleft$	Angle Angular value
	Warning Note	-		Preload
	Visual inspection Fitting position check	-		Number of revolutions
F	Measurement Value to find Check	-		Temperature
P	Equipment	-	bar	Pressure
24	Surface for machining Machine finish	-	>	Oversized Higher than Maximum, peak
-¢	Interference Strained assembly	-	<	Undersized Less than Minimum
	Thickness Clearance	-	A	Selection Classes Oversizing
	Lubrication Damp Grease	-		Temperature < 0 °C Cold Winter
	Sealant Adhesive	-	<b>\</b>	Temperature > 0 °C Hot Summer
	Air bleeding	-		
		-		

### **GENERAL WARNINGS**



Warnings shown cannot be representative of all danger situations possibly occurring. Therefore, it is suggested to contact immediate superiors where a danger situation occurs which is not described.

Use both specific and general-purpose toolings according to the prescriptions contained in respective use and maintenance handbooks. Check use state and suitability of tools not subjected to regular check.

The manual handling of loads must be assessed in advance because it also depends, besides weight, on its size and on the path.

Handling by mechanical means must be with hoisters proper as for weight as well as for shape and volume. Hoisters, ropes and hooks used must contain clear indications on maximum carrying capacity acceptable. The use of said means is compulsorily permitted to authorised personnel only. Stay duly clear of the load, and, anyhow, never under it.

In disassembling operations, always observe provided prescriptions; prevent mechanical parts being taken out from accidentally striking workshop personnel.

Workshop jobs performed in pairs must always be performed in maximum safety; avoid operations which could be dangerous for the co-operator because of lack of visibility or of his/her not correct position.

Keep personnel not authorised to operations clear of working area.

You shall get familiar with the operating and safety instructions for the assembly prior to operating on the latter. Strictly follow all the safety indications found on the assembly.

Do not leave the running assembly unattended when making repairs.

When carrying out work on the assembly lifted off the ground, verify that the assembly is firmly placed on its supporting stands, and that the manual/automatic safety devices have been actuated in the event that the assembly is to be lifted by means of a hoist.

When you have to operate on assemblies powered by natural gas, follow the instructions contained in the document, as well as all the specific safety standards provided for.

Only remove radiator cap when the engine is cold by cautiously unscrewing it in order to let system residual pressure out.

Inflammable fuel and all inflammable fluids and liquids must be handled with care, according to what contained on harmful materials 12-point cards. Refuelling must be performed outdoors with the engine off, avoiding lit cigarettes, free flames or sparks in order to prevent sudden fires/bursts. Adequately store inflammable, corrosive and polluting fluids and liquids according to what provided by regulations in force. Compulsorily avoid to use food containers to store harmful liquids. Avoid to drill or bore pressurised containers, and throw cloths impregnated with inflammable substances into suitable containers.

Worn out, damaged or consumable parts must be replaced by original spares.

During workshop activity, always keep the work place clean; timely clear or clean floors from accidental liquid or oil spots. Electric sockets and electric equipment necessary to perform repair interventions must meet safety rules.



Put on, where required by the intervention, garments and protections provided in accident prevention rules; contact with moving parts can cause serious injuries. Use suitable, preferably tight-fitted garments, and avoid to use jewels, scarves, etc.

Do not leave the engine in motion at workshop locations not provided with a pipe to scavenge exhaust gas outside.

Avoid to breathe fumes coming from heating or from paint welding because they can cause damages to health; operate outdoors or in suitably ventilated areas. Put on proper inspirator if paint powder is present.

Avoid contact with hot water or steam coming from the engine, radiator and pipings because they could cause serious burns. Avoid direct contact with liquids and fluids present in vehicle systems; where an accidental contact has occurred, refer to 12-point cards for provisions to make.



Clean the assemblies and carefully verify that they are intact prior to overhauling. Tidy up detached or disassembled parts with their securing elements (screws, nuts, etc.) into special containers.

Check for the integrity of the parts which prevent screws from being unscrewed: broken washers, dowels, clips, etc. Self-locking nuts with an insert made of nylon must always be replaced.

Avoid contact of rubber parts with diesel oil, petrol or other not compatible substances.

Before washing under pressure mechanical parts, protect electric connectors, and central units, if present.

Tightening screws and nuts must always be according to prescriptions; FPT commercial and assistance network is available to give all clarifications necessary to perform repair interventions not provided in this document.

Before welding:

- Disconnect all electronic central units, take power cable off battery positive terminal (connect it to chassis bonding) and detach connectors.
- Remove paint by using proper solvents or paint removers and clean relevant surfices with soap and water.
- Await about 15 minutes before welding.
- Equip with suitable fire resistant protections to protect hoses or other components where fluids or other materials flow which may catch fire easily on welding.

Should the vehicle be subjected to temperatures exceeding 80°C (dryer ovens), disassemble drive electronic central units.



The disposal of all liquids and fluids must be performed with full observance of specific rules in force.

GENER	AL WARNINGS ON THE ELECTRIC SYSTEM
!	If an intervention has to be made on the electric/electronic system, disconnect batteries from the system; in this case, always disconnect, as a first one, the chassis bonding cable from batteries negative terminal.
	Before connecting the batteries to the system, make sure that the system is well isolated.
	Disconnect the external recharging apparatus from the public utility network before taking apparatus pins off battery terminals.
	Do not cause sparks to be generated in checking if the circuit is energised.
	Do not use a test lamp in checking circuit continuity, but only use proper control apparatuses.
	Make sure that the electronic devices wiring harnesses (length, lead type, location, strapping, connection to screening braiding, bonding, etc.) comply with FPT system and are carefully recovered after repair or maintenance interventions.
	Measurements in drive electronic central units, plugged connections and electric connections to components can only be made on proper testing lines with special plugs and plug bushes. Never use improper means like wires, screwdrivers, clips and the like in order to avoid the danger of causing a short circuit, as well as of damaging plugged connections, which would later cause contact problems.
	To start up the engine, do not use fast chargers. Start up must only be performed with either separate batteries or special truck.
	A wrong polarisation of supply voltage in drive electronic central units (for instance, a wrong polarisation of batteries) can cause them to be destroyed.
	Disconnect the batteries from the system during their recharging with an external apparatus.
	On connecting, only screw up connector (temperature sensors, pressure sensors etc.) nuts at prescribed tightening torque.
	Before disconnecting the junction connector from an electronic central unit, isolate the system.
	Do not directly supply electronic central units servo components at nominal vehicle voltage.
	Cables must be arranged such as to result to be parallel to reference plane, i.e. as close as possible to chassis/body structure.
	Once the intervention on the electric system has been completed, recover connectors and wiring harnesses according to original arrangement.
ΝΟΤΕ	Connectors present must be seen from cable side. Connectors views contained in the manual are representative of cable side.

#### **Bonding and screening**

Negative leads connected to a system bonded point must be both as short and possible and "star"-connected to each other, trying then to have their centering tidily and properly made (Figure 1, re. M).

Further, following warnings are to be compulsorily observed for electronic components:

- Electronic central units must be connected to system bonding when they are provided with a metallic shell.
- Electronic central units negative cables must be connected both to a system bonding point such as the dashboard opening bonding (avoiding "serial" or "chain" connections), and to battery negative terminal.
- Analog bonding (sensors), although not connected to battery negative system/terminal bonding, must have optimal isolation. Consequently, particularly considered must be parasitic resistances in lugs: oxidising, clinching defects, etc.
- Screened circuits braiding must only electrically contact the end towards the central unit entered by the signal (Figure 2).
- If junction connectors are present, unscreened section d, near them, must be as short as possible (Figure 2).
- Cables must be arranged such as to result to be parallel to reference plane, i.e. as close as possible to chassis/body structure.



## **OPTIONAL ELECTRICAL AND MECHANICAL PARTS INSTALLATIONS**

Assemblies shall be modified and equipped with additions - and their accessories shall be fitted - in accordance with the assembling directives issued.

It is reminded that, especially about the electric system, several electric sockets are provided for as series (or optional) sockets in order to simplify and normalise the electrical intervention that is care of preparation personnel.



It is absolutely forbidden to make modifications or connections to electric central units wiring harnesses; in particular, the data interconnection line between central units (CAN line) is to be considered inviolable.

# CONVERSIONS BETWEEN THE MAIN UNITS OF MEASUREMENT OF THE INTERNATIONAL SYSTEM AND MOST USED DERIVED QUANTITIES

#### Power

kW	=	1.36 metric HP
kW	=	1.34 HP
metric HP	=	0.736 kW
metric HP	=	0.986 HP
HP	=	0.746 kW
HP	=	1.014 metric HP
	kW kW metric HP metric HP HP HP	kW=kW=metric HP=HP=HP=

#### Torque

l Nm	=	0.1019 kgm
l kgm	=	9.81 Nm

#### Revolutions per time unit

l rad/s	=	l rpm x 0.1046
l rpm	=	I rad/s x 9.5602

#### Pressure

l bar	=	1.02 kg/cm <sup>2</sup>
l kg/cm <sup>2</sup>	=	0.981 bar
l bar	=	10 <sup>5</sup> Pa

Where accuracy is not particularly needed:

Nm unit is for the sake of simplicity converted into kgm according to ratio 10:1

I kgm = I0 Nm;

 $\Box$  bar unit is for the sake of simplicity converted into kg/cm<sup>2</sup> according to ratio 1:1

 $| kg/cm^2 = | bar.$ 

#### Temperature

0°C = 32°F |°C = (|×|.8 + 32)°F



# Part I F2C CURSOR ENGINES Section General specifications Fuel

Industrial application	3
Overhaul and technical specifications	4
Tools	5

# Safety prescriptions

I

2

## UPDATING

Section	Description	Page	Date of revision
1			

# SECTION I

# **General Specifications**

		Page
MA	PPING BETWEEN TECHNICAL AND COMMERCIAL CODING	3
VIE	WS OF THE ENGINE	5
LUE	BRICATION DIAGRAM	8
	Oil pump	9
	Overpressure valve	9
	Oil pressure control valve	10
	Heat exchanger	10
ENG	GINE OIL FILTER	11
	Characteristics	11
	Lock torques	11
	Installation rule	11
	Filter by-pass valve	
	Replacing oil filter cartridge	12
	Dismantling	12
	Refitting	12
	Oil fume recycle (Blow-by)	13
CO	OLING	14
	Description	14
	Operation	14
	Water pump	16
	Thermostat	16
TUF	RBOCHARGING	17
EGF	R EXHAUST GAS RECYCLE SYSTEM	18
	ERNAL EGR OPERATING ON SUCTION /ALVES	18

# MAPPING BETWEEN TECHNICAL AND COMMERCIAL CODING

Technical Code	Commercial Code	
F2CE9687B*E001	C87 ENT X	
FZCE960/A'EUUT		











1. Overpressure valve – Start of opening pressure 10.1  $\pm$ 0.7 bars.



I. Exchanger seal - 2. Internal heat exchanger element - 3. Cover - 4.Oil filter - 5. Oil filter seal



9. Plug M14x1.5 - 10. Plug M38x1.5 - 11. By-pass valve 3.4 bars.

### Characteristics

- I. Max working pressure: 13 bars
- 2. Working temperature:  $30^{\circ} \text{ C} \div + 120^{\circ} \text{ C}$
- 3. By-pass valve opening value: 3,4 ± 0,3 bar

# Lock torques

Cap (part I):	60 ± 5 Nm
Plug (part 9):	30 ± 5 Nm
Plug (part 10):	90 ± 5 Nm

# Installation rule

Use threadlock for plug (part 10).





Remove the plug (2).

Undo the filter casing (1) by a couple of turns and wait for a few minutes.

In this way the remaining oil in the casing starts firstly to drip and then to flow smoothly out.

Completely undo the casing and then replace the cartridge.

# Refitting



Insert the cartridge in the casing aligning the centering tabs(2) on the upper plate (1) with the seats.

The cartridge should be pushed into the container until the action of the attachment system at the bottom of the casing is overcome.

At the same time, the tabs on the upper plate should slide into the housings.



Move the upper part of the casing thread close to the first lower thread of the support (the cartridge cover element should be in contact with the oil outlet duct on the support.

Proceed with tightening the cartridge-casing assembly (1) on the support (4).

During this stage both the seal (3) for the oil outlet duct-cartridge element and the casing-support seal (2) will gradually be involved.

Tighten the filter casing to a torque of 65 Nm.

### Figure 18



||5879

Tighten the protective cap (1) on the filter casing.

# Oil fume recycle (Blow-by)

Part of gas produced by combustion during engine operation leaks through piston elastic ring openings into sump, mixing with oil fumes in sump.

This mixture, conveyed upward, is partially separated from oil by a device located in timing cover upper part and introduced in air intake circuit.

The device mainly consists of a rotary filter secured on propeller shaft and by a front cover housing normally closed valves controlling mixture flow.



# COOLING

#### Description

The engine cooling system is of the closed-circuit, forced circulation type. It consists mainly of the following components:

- expansion tank, not supplied (by FPT);
- a heat exchanger to cool down lubrication oil;
- a water pump with centrifugal system incorporated in the cylinder block;
- fan, not supplied;
- a 2-way thermostat controlling the coolant circulation.

#### Operation

The water pump is actuated by the crankshaft through a poli-V belt and sends coolant to the cylinder block, especially to the cylinder head (bigger quantity). When the coolant temperature reaches and overcomes the operating temperature, the thermostat is opened and from here the coolant flows into the radiator and is cooled down by the fan. The pressure inside the system, due to temperature change, is adequately controlled through the expansion vessel.







# EGR EXHAUST GAS RECYCLE SYSTEM

The exhaust gas can be partially recycled to cylinders to reduce maximum temperature values of combustion that produce nitrogen oxides (NOx).

The exhaust gas recycle system (EGR) reduces combustion temperature and therefore is an efficient NOx emission control system.

# INTERNAL EGR OPERATING ON SUCTION VALVES

The specific design of suction cams of the internal EGR system allows part of exhaust gas to be recycled to engine cylinders. This type of EGR, called internal EGR, is not equipped with any electronic control, the system is always active. Its configuration requires no additional parts such as control valves, pipelines or heat exchangers therefore engine profile remains unchanged Besides main lobe, suction cam has an additional lobe (3) as to configuration without EGR. During concerned cylinder exhaust phase, this lobe allows a shaft advanced opening of intake valve (\*). In this way, part of the exhaust gas is trapped in the suction duct and later, during cylinder suction phase, this gas is recycled to cylinder inlet for combustion phase.


# SECTION 2 Fuel

	Page
SUPPLY	. 3
FUEL SUPPLY DIAGRAM	. 4
MECHANICAL SUPPLY PUMP	. 5
Normal operating conditions	5
Overpressure condition at outlet	5
Drain conditions	5
CP3 HIGH-PRESSURE PUMP	. 6
HIGH-PRESSURE PUMP - INSIDE STRUCTURE	7
Operating principle	8
Operation	10
RAIL (PRESSURE ACCUMULATOR)	. 10
	10

## SUPPLY

The Common Rail supply system is equipped with a special pump that maintains fuel at constant high pressure regardless from phase and cylinder under injection and accumulated in an common duct shared by all electric injectors.

Therefore, fuel at injection pressure, calculated by ECU, is always available at electric injection inlet.

When the solenoid value of an injector is energized by ECU, in related cylinder the injection of fuel taken directly from the rail takes place.

Figure I Return circuit Supply circuit







F2C CURSOR ENGINES





1. Fuel outlet fitting to rail - 2. Delivery valve to rail - 3. Pumping element - 4. Pump shaft - 5. Pumping element supply duct - 6. Pressure regulator supply duct - 7. Pressure regulator

Pumping element (3) is oriented to pump shaft (4) cam. During intake, the pumping element is supplied through supply duct (5). The fuel amount to be sent to the pumping element is set by the pressure regulator (7). The pressure regulator meters fuel flow to pumping element according to the PWM signal received from ECU. During pumping element compression stage, fuel reaches the pressure required to open the delivery valve to common rail (2) and to feed it through outlet (1).



Pump shaft is lubricated by fuel through delivery and return ducts (2).

Pressure regulator (5) establishes the fuel amount to send to pumping elements; excess fuel is drained out through duct (9).

5 bar pressure relief valve acts as fuel exhaust manifold and keeps 5 bar constant pressure at regulator inlet.



I. Fuel outlet duct - 2. Fuel outlet duct - 3. Fuel outlet from pump with high pressure pipe fitting for common rail

Figure 10 shows high pressure fuel flow through pumping element outlet ducts.

## Operation

The cylinder is filled through the cap intake valve only if the supply pressure is suitable to open the delivery valves set on the pumping elements (about 2 bars).

The amount of fuel supplying the high-pressure pump is metered by the pressure regulator, placed on the low-pressure system; the pressure regulator is controlled by the EDC7 control unit through a PWM signal.

When fuel is sent to a pumping element, the related piston is moving downwards (suction stroke). When the piston stroke is reversed, the intake valve closes and the remaining fuel in the pumping element chamber, not being able to come out, is compressed above the supply pressure value existing in the rail.

The thereby-generated pressure makes the exhaust valve open and the compressed fuel reaches the high-pressure circuit.

The pumping element compresses the fuel till the top dead center (delivery stroke) is reached. Afterwards, the pressure decreases till the exhaust valve is closed.

The pumping element piston goes back towards the bottom dead center and the remaining fuel is decompressed.

When the pumping element chamber pressure becomes less than the supply pressure, the intake valve is again opened and the cycle is repeated.

The delivery valves must always be free in their movements, free from impurities and oxidation.

The rail delivery pressure is modulated by the electronic control unit, through the pressure regulator solenoid valve.

The pump is lubricated and cooled by the fuel.

The radialjet pump disconnection – reconnection time on the engine is highly reduced in comparison with traditional injection pumps, because it does not require setting.

If the pipe between fuel filter and high-pressure pump is to be removed-refitted, be sure that hands and components are absolutely clean.

## **RAIL (PRESSURE ACCUMULATOR)**





I. Rail - 2. Fuel return - 3.Pipelines to injectors - 4. Fuel supply to high pressure pump - 5. Pressure sensor -6. Overpressure valve

The rail volume is of reduced sizes to allow a quick pressurisation at startup, at idle and in case of high flow-rates.

It anyway has enough volume as to minimise use of plenum chambers caused by injectors openings and closings and by the high-pressure pump operation. This function is further enabled by a calibrated hole being set downstream of the high-pressure pump.

A fuel pressure sensor (5) is screwed to the rail. The signal sent by this sensor to the electronic control unit is a feed-back information, depending on which the rail pressure value is checked and, if necessary, corrected.

## Electroinjector

Figure 12



#### SECTION 3 Industrial application Page CLEARANCE DATA ..... 3 PART ONE -MECHANICAL COMPONENTS ..... 5 7 ENGINE DISASSEMBLY ON BENCH ..... ASSEMBLY ..... ||15 High pressure pump installation ..... ENGINE FLYWHEEL ..... 15 15 Engine flywheel installation ..... 16 Camshaft installation ..... TIMING CAMSHAFT AND FLYWHEEL USING TOOL 99395223 ..... 17 Timing camshaft 17 19 Timing flywheel ..... TIMING CAMSHAFT AND FLYWHEEL WITHOUT TOOL 99395223 ..... 19 19 Timing camshaft Timing flywheel ..... 22 Intake and exhaust rocker arm clearance 23 ENGINE ASSEMBLY COMPLETION ..... 24 PART TWO -ELECTRICAL EQUIPMENT 27 29 Components on the engine F2C . . . . . . . . . Engine cable ..... 30 EDC 7 UC31 control unit pin-out 31 EDC 7 UC31 electronic control unit ..... 32 EDC control unit PIN-OUT 33 35 Electroinjectors Engine coolant temperature sensor ..... 36 $\Box$ 37

F2C CURSOR	<b>FNGINES</b>
120 0010010	E1 1 0 11 1 E 0

		Page
High pressure	e pump (pressure regulator)	38
Flywheel puls	e transmitter	39
Distribution p	oulse transmitter	40
<b>G</b> Fuel pressure	sensor on rail	43
Alternator		44
Starting moto	r	45
EDC SYSTEM FUI	NCTIONS	46
PART THREE - TI	ROUBLESHOOTING	49
METHODS OF D	IAGNOSIS	51
PT-01 PORTABLE	TESTER	52
Main function	IS	52
Test paramet	ers	52
PREFACE		53
FAULT CODES .		54
PART FOUR - MAINTENANG	CE PLANNING	57
MAINTENANCE	·····	59
Maintenance	services chart	59
CHECKS AND/OI	R MAINTENANCE WORK	60
OFF-PLANE OPE	RATIONS	61

F2C CURSOR ENGINES

CLEARANCE DATA			TECHNICAL CODE	
Туре		F2CE9687		
		A*E	B*E	
1	Cycle		4-stroke Diesel engine	4-stroke Diesel engine
	Fuel feed		Turbocharged	Turbocharged
	Injection		Direct	
	No. of cylinders •		6 in line	
	Bore mm		117	
	ج آ Stroke mm		135	
	<b>4</b> Total displaceme	ent cm <sup>3</sup>	8710	
Q	Compression ratio		1: 15.9 ± 0.8	
	Maximum power	kW (HP) rpm	260 314 2100	230 305 2100
	Max. torque	Nm (kgm) rpm	1500	1400
	Loadless engine idling rpm			
	peak	rpm	-	-
	SUPERCHARGING		Interc Direct in	ooler njection
	lurbocharger type		HX40	
bar	Oil pressure (warm engine) - idling bar - peak rpm bar		Forced by gear pump, relief valve single action oil filter - -	
COOLING Water pump control		Liquid Through belt		
	Thermostat - start of opening	g °C	8	5
<ul> <li>NOTE Data, features and performances are valid only if the setter fully complies with all the installation prescriptions provided by FPT.</li> <li>Furthermore, the users assembled by the setter shall always be in conformance to couple, power and number of turns based on which the engine has been designed.</li> </ul>				

# PART ONE -

# MECHANICAL COMPONENTS





If air conditioner compressor is installed, cut belt (2) as it must not be reused.

Use specific tool (1) and operate in the arrow direction to remove water pump and alternator control belt (5).

Remove screws and separate pulleys (3) and (6) with damping flywheel (4).









Disconnect fuel lines (2), unlock retaining screws and remove high pressure pump (1). Remove fuel filter support (3) complete with pipeline.



Unlock screws (1) and remove thrust plate (2).

Use specific spanner to unlock screws (4) and remove relay gear (5).

Remove high pressure pump mount flange (3).



114009

Use specific tool lock engine flywheel (2) rotation, unlock retaining screws (1) and remove engine flywheel.







Install front cover (1) and lock retaining screw at required torque.

Check that the injectors (2) are equidistant from the springs (1). Distance "X" which separates them should always be the same.

## ASSEMBLY



Install front cover (1) and lock retaining screw at required torque.





- 3. Install pipes on rail and lock fittings by hand.
- 4. Lock rail to cylinder head retaining screws at required torque.













Fit the flywheel (4) so that the toothe marked with the arrow  $(\rightarrow)$  is in line with the sensor housing (6).

To check that the position is correct, insert tool 99360613 in the timing sensor (6) housing.

Proceed with tightening the bolts (5).

Remove the tools 99395223, 99360612 and 99360613.



**NOTE** The arrow indicated engine rotation direction.

Use tool above to rotate engine flywheel (1) in engine rotation direction to bring cylinder 1 piston approx. to TDC in blast phase.

This condition is reached when hole with notch (4), following hole with two notches (5) drilled on engine flywheel (1), is visible through manhole (2).



The exact position of piston no.1 at TDC is obtained when, in conditions described above, tool 99360612 (1), through engine rpm sensor housing (2), inserts in hole (3) drilled on engine flywheel (4).

Otherwise, rotate engine flywheel (4) to adjust its orientation.





## Zero set dial gage.

Rotate engine flywheel anticlockwise till dial gage reads camshaft cam lift value =  $4.70 \pm 0.05$  mm.



Camshaft is timed if conditions below are found at cam lift values  $4.70 \pm 0.05$ :

- hole identified with two notches (5) is visible through manhole;
- 2) fixture 99360612 (1) through housing (2) of engine rpm sensor inserts in hole (3) on engine flywheel (4).



114281

In case conditions shown in Figure 61 and shown at paras 1 and 2 are not found, operate as follows:

- release screws (2) securing gear (1) of camshaft to as to make control gear and camshaft independent;
- conveniently operate on engine flywheel so as to obtain conditions indicated at paras I and 2, Figure 61, considering that cam lift value must remain unchanged;
- 3) lock screws (2) and repeat control as already described;
- 4) lock screws (2) at required torque.





Install timing cover (1) and lock retaining screws (2) at required torque.



Adjustment of clearance between rocker arms and intake/exhaust valve control crosspieces must be performed with utmost care. Bring to blast phase cylinder to be adjusted; the valves of this cylinder are closed while the symmetric cylinder valves are balanced. Symmetric cylinders are 1-6; 2-5 and 3-4.

In order to perform these operations correctly, refer to procedure and table below.

- Use a polygonal spanner to release lock nut (1) of rocker arm adjustment screw (2).
- Insert filler gage (3) having same value of operating clearance shown in "Characteristic and data" tables.
- Use special spanner to lock/unlock adjustment screw.
- Check that filler gage (3) slides with a low friction.
- Lock nut (1) retaining the adjustment screw.

START AND ROTATION CLOCKWISE	BALANCE VALVES OF CYLINDER No.	ADJUST CLEARANCE OF VALVES CYLINDER No.
I and 6 at TDC	6	
120°	3	4
120°	5	2
120°	l	6
120°	4	3
120°	2	5

### IGNITION ORDER 1-4-2-6-3-5

**NOTE** In order to correctly carry out adjustments above, it is mandatory to perform the sequence indicated in the table, checking exact positioning at each phase by means of pin 99360612.



114288

Install blow-by body (1) with related seal and lock screws (2) at required torque.

Install cover (3) and lock screws (4) at required torque.



Install blow-by body (1) with related seal and lock screws (2) at required torque.

Install cover (3) and lock screws (4) at required torque.

#### F2C CURSOR ENGINES



Remove tool 99360612 (1, Figure 54).



Fit seal (4) on oil sump (1), fit spacer (3) and install sump on engine block locking screws (2) at required torque.

## **ENGINE ASSEMBLY COMPLETION**

Complete engine assembly fitting or connecting parts below:

- complete fuel filter support and pipelines;
- EDC ecu;
- intake manifold with pre-heating resistor;
- heat exchanger;
- exhaust manifold;
- turbocharger and related water and oil;
- pulley and damper flywheel assy (install fixed guide pulley
   5, Figure 3, before assy);
- thermostat assy;
- belt tensioner, water pump, alternator;
- oil level rod;
- start-up motor;
- oil filter;
- electric connections and sensors (See diagram on page 30).

**NOTE** Fittings of pipelines, cooling water and turbocharger lube oil must be locked at:

- 35 ± 5Nm, water pipeline fittings;
- 55 ± 5Nm, oil pipeline female fitting;
- 20-25 Nm, oil pipeline make fitting.


## PART TWO -

## **ELECTRICAL EQUIPMENT**

# **Components on the engine F2C** Figure I L N M $\cap$ ٩ A B I H) 0 G) F Ε С D 114294

A. Fuel temperature sensor - B. Engine rpm sensor on camshaft - C. Starter motor - D. EDC 7 control unit - E. Conditioner compressor - F. Pressure/temperature transmitter - G. Temperature/air pressure sensor - H. Alternator - I. Resistance for engine warming - L. Connector on engine block for connection with electro-injectors - M. Water temperature sensor - N. Engine speed on flywheel sensor - O. Fuel adjustment valve on high pressure pump



#### EDC 7 UC31 control unit pin-out Figure 3 $\odot$ 35 -мніте-вер-47042 18 ~~~~ -ORANGE-BLACK-26 -YELLOW-85153 15 ЫИК 28 BLUE-47032 27 ORANGE-BLACK 32 ۵ 42030 -ORANGE-∍ 24 -вкожи-36 -Эримяо 33 \_\_\_\_ CBEEN-85156 34 ۵. -RED-⇒ 25 - MHILE-12 - MOTTEA 85157 4 -ЭЭИАЯО ₽ ⇒ - MOLET S5 48042 თ ЭШНА 10 BED S6 6 { 48035 вгуск 23 Q - AHITE-EDC EDC7 9 2 2--X 78013 σ 15 $\bowtie$ Q 78247 2 16 78247 5 $\bowtie$ 4 $\bowtie$ 78247 м ŝ $\bowtie$ 78247 3 12 Ξ $\bowtie$ 78247\_2 9 4 78247 13 85150 $\triangleleft$

#### Print P2D32C006E

Base - June 2007

# EDC 7 UC31 electronic control unit Figure 4 С А ß £ ſſ ťΩ Ω П $\Box$ П Π BOSCH Π В 5) ((( )]) Ð 102373

A. Electro-injector connector - B. Chassis connector - C. Sensor connector

EDC con	trol unit PIN-OUT
Electric inie	ector connector "A"
Figure	5
	12 16
	5
Colour leg	end
B bla	ack
K re U blu	
W wł	nite
P pu	Irple
G gro N br	een own
Y ye	llow
O or	ange
<b>E</b> gre <b>K</b> pir	ey nk
р. р.	
Pin	Function
	Solenoid valve for electronic cylinder 5 injection
2	Solenoid valve for electronic cylinder 6 injection
3	Solenoid valve for electronic cylinder 4 injection
4	Solenoid valve for electronic cylinder I injection
5	Solenoid valve for electronic cylinder 3 injection
6	Solenoid valve for electronic cylinder 2 injection
/	
9	
10	
	Solenoid valve for electronic cylinder 2 injection
12	Solenoid valve for electronic cylinder 3 injection
13	Solenoid valve for electronic cylinder I injection
14	Solenoid valve for electronic cylinder 4 injection
15	Solenoid valve for electronic cylinder 6 injection
16	Solenoid valve for electronic cylinder 5 injection





#### Engine coolant temperature sensor

This N.T.C. type sensor located on the water outlet sump on the engine head left measures coolant temperature for the various operating logics with a hot or cold engine and identifies injection enrichment requirements for a cold engine or fuel reduction requirements for a hot engine.

It is connected to electronic center pins 15/26.





#### High pressure pump (pressure regulator)

Pump with 3 radial pistons commanded by timing gear, requiring no tuning, with rotor supply pump applied on rear end.

- A. Fuel drain outlet fitting to filter support
- B. Fuel inlet fitting from ECU heat exchanger
- C. Fuel inlet fitting from fuel filter
- D. Fuel outlet fitting from supply pump to filter
- E. Fuel outlet fitting to rail
- I. High-pressure pump
- 2. Supply pump
- **3.** Pressure regulator (NO solenoid valve modulated by ECU with PWM signal).

#### Pressure regulator

Located at high-pressure pump inlet, on low pressure system, it modulates the amount of fuel for high-pressure pump supply based on commands received from ECU.

It mainly consists of parts below:

- trapezoidal-section lock pin;
- valve control pin;
- pre-load valve;
- coils.

When no control signal is present, the pressure regulator is normally open, therefore the high pressure pump is in max delivery condition.

The ECU modulates a PWM control signal to extend or reduce section of fuel supply line to high-pressure pump.

The component cannot be replaced as an individual part, therefore it cannot be removed.

The quantity of high-pressure supply fuel is metered by a proportional valve positioned on low-pressure system and it is managed by the ECDC 7 ECU.

The delivery pressure to rail is modulated between 250 and 1400 bars by ECU operating on pressure regulator solenoid valve.

It is a NO solenoid valve.

Its resistance is ~ 3,2  $\Omega$ .

It is connected to ECU pins C5 - C7.



000912t



BOSCH 8 ± 2 Nm

880 ÷ 920  $\Omega$ 

#### **Distribution pulse transmitter**

Features

Vendor Torque

Resistance

This induction type sensor located on the camshaft generates signals obtained from the magnetic flow lines that close through the 6 plus I phase teeth of a sound wheel mounted on the shaft.

The electronic center uses the signal generated by this sensor as an injection step signal.

This sensor's air gap is NOT ADJUSTABLE.

Figure 12







В



Description	Cable colour
To EDC center pin 9 (Sensor connector ''C'')	W
To EDC center pin 10 (Sensor connector ''C'')	R



Wiring diagram

50344

#### Oil temperature/pressure sensor (42030 / 47032)

This component is identical to the air pressure/temperature sensor and replaced single sensors 47032 / 42030.

It is fitted onto the engine oil filter, in a horizontal position.

It measures the engine oil temperature and pressure.

The measured signal is sent to the EDC control unit which controls, in turn, the indicator instrument on the dashboard (low pressure warning lights / gauge).

Pin (EDC)	24/C - 32/C	Power supply
Pin (EDC)	27/C	Temperature
Pin (EDC)	28/C	Pressure

The engine oil temperature is used only by the EDC control unit.

Ref.	Description	Control unit pin
I	Ground	24C
2	Temp. Sign.	27C
3	+5	32C
4	Press. Sign.	28C



#### Fuel pressure sensor on rail

Installed on one rail end, it measures actual fuel pressure in order to determine injection pressure.

The injection pressure value is used for pressure check and to determine the injection electric command duration.

It is supplied with 5 volts.

Figure 19

It is connected to ECU on pins 12C - 13C - 14C.





Ref.	Description	Pin ecu
I	ECU pin	I2C
2	Ground	I3C
3	Supply Pressure	I4C





## **EDC SYSTEM FUNCTIONS**

The EDC 7 UC31 electronic center manages the following main functions:

Fuel injection

Accessory functions such as cruise control, speed limiter, PTO and the like Self-diagnosis Recovery

It also enables:

Interfacing with other electronic systems (if any) available on the vehicle

Diagnosis

#### Fuel dosing

Fuel dosing is calculated based on:

- accelerator position
- engine rpm
- quantity of air admitted.

The result can be corrected based on:

- water temperature

- or to prevent:
- noise
- fumes
- overloads
- overheating

Pressure can be adjusted in case of:

- engine brake actuation
- external device actuation (e.g. speed reducer, cruise control)
- serious defects involving load reduction or engine stop.

After determining the mass of air introduced by measuring its volume and temperature, the center calculates the corresponding mass of fuel to be injected into the cylinder involved, with account also taken of gas oil temperature.

#### Delivery correction based on water temperature

When cold, the engine encounters greater operating resistance, mechanical friction is high, oil is till very viscous and operating plays are not optimized yet.

Fuel injected also tends to condense on cold metal surfaces.

Fuel dosing with a cold engine is therefore greater than when hot.

#### Delivery correction to prevent noise, fumes or overloads

Behaviors that could lead to the defects under review are well known, so the designer has added specific instructions to the center to prevent them.

#### De-rating

In the event of engine overheating, decreasing delivery proportionally to the temperature reached by the coolant changes injection.

#### Injection lead electronic control

Injection lead, or the start of fuel delivery expressed in degrees, can differ from one injection to the next, even from one cylinder to another and is calculated similarly to delivery according to engine load, namely, accelerator position, engine rpm and air admitted. Lead is corrected as required:

- during acceleration
- according to water temperature
- and to obtain:
- reduced emissions, noise abatement and no overload
- better vehicle acceleration
- High injection lead is set at start, based on water temperature.

Delivery start feedback is given by injection electro valve impedance variation.

#### Engine start

Cylinder I step and recognition signal synchronization (flywheel and drive shaft sensors) takes place at first engine turns. Accelerator pedal signal is ignored at start. Star delivery is set exclusively based on water temperature, via a specific map. The center enables the accelerator pedal, when it detects flywheel acceleration and rpm such as to consider the engine as started and no longer drawn by the starter motor.

#### Run Up

When the ignition key is inserted, the center transfers data stored at previous engine stop to the main memory (Cf. After run), and diagnoses the system.

#### After Run

At each engine stop with the ignition key, the center still remains fed by the main relay for a few seconds, to enable the microprocessor to transfer some data from the main volatile memory to an non-volatile, cancelable and rewritable (Eeprom) memory to make tem available for the next start (Cf. Run Up).

These data essentially consists of:

- miscellaneous settings, such as engine idling and the like
- settings of some components
- breakdown memory

The process lasts for some seconds, typically from 2 to 7 according to the amount of data to be stored, after which the ECU sends a command to the main relay and makes it disconnect from the battery.

This procedure must never be interrupted, by cutting the engine off from the battery cutout or disconnecting the latter before 10 seconds at least after engine cutout.

In this case, system operation is guaranteed until the fifth improper engine cutout, after which an error is stored in the breakdown memory and the engine operates at lower performance at next start while the EDC warning light stays on.

Repeated procedure interruptions could in fact lead to center damage.

#### Cut-off

It refers to the supply cut-off function during deceleration.

#### Cylinder Balancing

Individual cylinder balancing contributes to increasing comfort and operability.

This function enables individual personalized fuel delivery control and delivery start for each cylinder, even differently between each cylinder, to compensate for injector hydraulic tolerances.

The flow (rating feature) differences between the various injectors cannot be evaluated directly by the control unit. This information is provided by the entry of the codes for every single injector, by means of the diagnosis instrument.

#### **NOTE** Not present on agricultural versions.

## Synchronization search

The center can anyhow recognize the cylinder to inject fuel into even in the absence of a signal from the camshaft sensor. If this occurs when the engine is already started, combustion sequence is already acquired, so the center continues with the sequence it is already synchronized on; if it occurs with the engine stopped, the center only actuates one electro valve. Injection occurs onside that cylinder within 2 shaft revs at the utmost so the center is only required to synchronize on the firing sequence and start the engine.

## **PART THREE - TROUBLESHOOTING**



## **PT-01 PORTABLE TESTER**

Using PT-01 with portable tester it is possibile to execute troubleshooting and test the EDC7 electronic module of NEF engines.

PT-01 has been designed and developed to ensure stoutness and practicality and is particularly suitable to be used in workshop and industrial environment.

The tool is connected to the engine gearbox by means of one only cable providing both tester feed and communication with the electronic module.

## **Main functions**

**NOTE** Before connecting the tester to the electronic module, check the wording on the electronic module to select the correct software on the tool.



Easy access to different functions is available through the menu:

- ID. Reading of the electronic module;
- Reading of failure memory and relevant environment conditions;
- Failure memory clear;
- Reading of working parameters;
- Reading of status parameters;
- Active troubleshooting (switching on heat starter, fuel pump, EDC warning led and so on)

#### Test parameters

- Engine revolutions;
- Spark advance;

\_

-

\_

\_

\_

- Battery voltage;
- Accelerator foot pedal position;
- Over voltage pressure;
- Over voltage air temperature;
- Cooling liquid temperature;
- Fuel temperature;
- Oil temperature;
- Oil pressure;
- Fuel delivery;
- Fuel pressure;
- Rail pressure duty cycle electro-valve.

## PREFACE

A successful troubleshooting is carried out with the competence acquired by years of experience and attending training courses.

When the user complains for bad efficiency or working anomaly, his indications must be kept into proper consideration using them to acquire any useful information to focus the intervention.

After the detection of the existing anomaly, it is recommended to proceed with the operations of troubleshooting by decoding the auto-troubleshooting data provided by the EDC system electronic central unit.

The continuous efficiency tests of the components connected to, and the check of working conditions of the entire system carried out during working, can offer an important diagnosis indication, available through the decoding of the "failure/anomaly" codes issued by blinking of the failure led: the "blink-code" (whether programmed).

Please consider that the interpretation of the indications provided by the blink-code is not sufficient to guarantee the solution to the existing anomalies.

Using FPT processing instruments, it is also possible to establish a bi-directional connection with the central unit, by which not only to decoding the failure codes but also input an enquiry relying on memory files, in order to achieve any further necessary information to identify the origin of the anomaly. Every time there is a breakdown claim and this breakdown is actually detected, it is necessary to proceed inquiring the electronic unit in one of the ways indicated and then proceed with the diagnostic research making trials and tests in order to have a picture of the working conditions and identify the root causes of the anomaly.

In case the electronic device is not providing any indication, it will be necessary to proceed relying on the experience, adopting traditional diagnosis procedures.

In order to compensate the operators' lack of experience in this new system, we are hereby providing the USER's GUIDELINE FOR TROUBLESHOOTING in the following pages.



Any kind of operation on the electronic center unit must be executed by qualified personnel, duly authorized by FPT.

Any unauthorized tamper will involve decay of after-sales service in warranty.

## FAULT CODES

Failure code	Failure description		
	Vehicle I ((Sensors / Consistency tests)		
1.1.2	ACCELERATOR PEDAL		
1.1.9	PLAUSIBILITY +15		
1.1.A	PLAUSIBILITY +50		
	Vehicle 2 (Indicator lamps / Relais / Actuators)		
1.2.3	EDC LAMP		
1.2.5	MAIN RELAY DEFECT		
1.2.6	BATTERY VOLTAGE		
1.2.8	MAIN RELAY - SHORT CIRCUIT TO BATTERY		
1.2.9	AIR-CONDITIONER COMPRESSOR RELAY		
I.2.B	THERMOSTARTER RELAY   (HEATER)		
1.2.E	MANAGEMENT SYSTEM PRE/POST-HEATING (ACTIVE)		
2.2.5	INTERRUPTED AFTER-RUN		
2.2.8	MAIN RELAY - SHORT CIRCUIT TO GROUND		
	Engine I (Temperature and pressure sensors)		
1.3.1	COOLANT TEMPERATURE SENSOR		
1.3.2	COOLANT TEMPERATURE SENSOR (TEST)		
1.3.3	AIR TEMPERATURE SENSOR BOOST AIR		
1.3.4	BOOST PRESSURE SENSOR		
1.3.5	FUEL TEMPERATURE SENSOR		
1.3.6	RAIL PRESSURE SENSOR OR SIGNAL ERROR		
1.3.7	DBV VALVE MANAGEMENT (BOOST PRESSURE)		
1.3.8	OIL PRESSURE SENSOR		
1.3.A	OIL TEMPERATURE SENSOR		
2.3.2	COOLANT TEMPERATURE SENSOR ABSOLUTE TEST		
2.3.6	RAIL PRESSURE SENSOR OFFSET		
2.3.8	OIL LOW PRESSURE		
2.3.A	OIL TEMPERATURE ABOVE NORMAL		
	Engine 2 (Speed sensors/actuators)		
1.4.1	CRANKSHAFT SPEED		
1.4.2	ENGINE WORKING ONLY WITH CAMSHAFT SENSOR		
1.4.3	CAMSHAFT SENSOR		
1.4.4	FAULT BETWEEN FLYWHEEL SENSOR AND CAMSHAFT		
	Damage information		
1.4.D	ENGINE OVERSPEED		
1.5.B	HIGH PRESSURE TEST (DEACTIVATES RAIL PRESS.MONITORING)		
1.9.D	INDICATES TORQUE LIMITATION DUE TO PERFORMANCE LIMITER		
4.9.E	INDICATES THE TORQUE LIMITATION DUE TO ENGINE PROTECTION		
6.9.E	INDICATES TORQUE LIMITATION DUE TO FUEL QUANTITY LIMITATION		

Failure code	Failure description
	Fuel metering
1.5.1	HIGH PRESSURE SYSTEM
1.5.2	FAULT ON THE FUEL PRESSURE CONTROL OF THE RAIL (POSITIVE DEVIATION)
1.5.3	FAULT ON THE FUEL PRESSURE CONTROL OF THE RAIL (NEGATIVE DEVIATION)
1.5.4	RAIL PRESSURE ERROR: TOO LOW
1.5.5	RAIL PRESSURE ERROR: TOO HIGH
1.5.6	HIGH PRESSURE SYSTEM
1.5.7	ERROR ON THE RAIL PRESSURE (EXCESSIVE DUTY CYCLE)
1.5.8	HIGH PRESSURE SYSTEM
1.5.9	PRESSURE MPROP REGULATOR ERROR
2.5.9	PRESSURE MPROP REGULATOR ERROR (SHORT CIRCUIT TO POSITIVE)
3.5.9	SHORT CIRCUIT TO GROUND OF METERING UNIT OUTPUT
	Injectors I
1.6.1	INJECTOR CYLINDER I / SHORT CIRCUIT
1.6.2	INJECTOR CYLINDER 2 / SHORT CIRCUIT
1.6.3	INJECTOR CYLINDER 3 / SHORT CIRCUIT
1.6.4	INJECTOR CYLINDER 4 / SHORT CIRCUIT
1.6.5	INJECTOR CYLINDER 5 / SHORT CIRCUIT
1.6.6	INJECTOR CYLINDER 6 / SHORT CIRCUIT
1.6.7	INJECTOR CYLINDER I / OPEN CIRCUIT
1.6.8	INJECTOR CYLINDER 2 / OPEN CIRCUIT
1.6.9	INJECTOR CYLINDER 3 / OPEN CIRCUIT
1.6.A	INJECTOR CYLINDER 4 / OPEN CIRCUIT
1.6.B	INJECTOR CYLINDER 5 / OPEN CIRCUIT
1.6.C	INJECTOR CYLINDER 6 / OPEN CIRCUIT
1.6.E	THE MINIMUM NUMBER OF INJECTIONS WAS NOT REACHED: STOP THE ENGINE
	Injectors 2
1.7.1	BENCH I CC
1.7.3	BENCH 2 CC
1.7.C	BENCH I INJECTORS CHECK (INTERNAL ECU)
2.7.C	BENCH 2 INJECTORS CHECK (INTERNAL ECU)
	Boosting system and turbine speed
I.9.E	TORQUE REDUCTION DUE TO SMOKE LIMITATION
	Interfaces I (CAN-Bus)
I .B. I	ERROR ON CAN CONTROLLER A
I.B.3	ERROR ON CAN CONTROLLER C
I.B.4	TIMEOUT CAN MESSAGE BC2EDC1
I.B.5	TIMEOUT CAN MESSAGE VM2EDC
I.B.D	TIMEOUT CAN MESSAGE CCVS
2.B.4	TIMEOUT CAN MESSAGE BC2EDC2
	Interfaces 2 (CAN line timeout messages)
I.C.6	ERROR MESSAGE CAN TSCI-PE

Failure code	Failure description
I.C.8	ERROR MESSAGE CAN TSCI-VE
1.C.9	ERROR MESSAGE CAN TF
2.C.6	TIMEOUT OF CAN MESSAGE TSCI-PE PASSIVE
3.C.8	TIMEOUT OF CAN MESSAGE TSCI-VE PASSIVE
ECU I (internal checks)	
1.D.1	ECU OVERRUN MONITORING ERROR
I.D.2	ECU OVERRUN MONITORING ERROR
I.D.3	ECU OVERRUN MONITORING ERROR
I.D.4	ECU OVERRUN MONITORING ERROR
1.D.5	ECU OVERRUN MONITORING ERROR
1.D.6	ECU INTERNAL ERROR (TPU)
I.D.7	INTERNAL ECU ERROR (VARIANT AREA)
I.D.8	ECU OVERRUN MONITORING ERROR
1.D.9	ECU OVERRUN MONITORING ERROR
2.D.3	ECU OVERRUN MONITORING ERROR
3.D.3	ERRORE INTERNO CENTRALINA
	ECU 2 (Power supply / Immobilizer / Runaway / Sensor power supply)
1.E.1	ECU: SHORT CIRCUIT OR OPEN CIRCUIT
I.E.3	ERROR FOR ECU INTERNAL MONITORING
I.E.4	ERROR FOR ECU INTERNAL MONITORING
I.E.5	SENSORS POWER SUPPLY FAULT (12V)
I.E.6	SENSOR POWER SUPPLY I
I.E.7	SENSOR POWER SUPPLY 2
I.E.8	SENSOR POWER SUPPLY 3
I.E.9	ECU OVERRUN MONITORING ERROR
I.E.A	ECU OVERRUN MONITORING ERROR
I.E.B	ATMOSPHERIC PRESSURE SENSOR
2.E. I	SHORT CIRCUIT TO BATT OR GROUND, NO LOAD, EXCESS.TEMP. FOR LOW SIDE POWER STAGE

## PART FOUR -

## MAINTENANCE PLANNING

MAINTENANCE Maintenance services chart The covered distances indicated in this schedule are typical of engines used in vehicles.	
	The kilometre frequency for engine lubrication is in relation to a percentage of sulphur in diesel of under 0.5%.
	NOTE: If using diesel with a percentage of sulphur above 0.5%, the oil-change frequency has to be halved.
Use eng	gine oil: ACEA E3 - 96
	<ul> <li>In the case of very low annual mileage of less than 600 hours, the engine oil and filters must be changed every 12 months.</li> <li>Premature clogging of the air cleaner is generally due to the operating conditions. The filter should therefore be renewed whenever clogging is signalled by the sensor regardless of the prescribed time interval, which should in any case be respected in the absence of any specific indications.</li> </ul>
	The covered distances specified in this schedule are provided purely as indications, owing to their being typical of average use of vehicle engines related to their displacement.

#### **CHECKS AND/OR MAINTENANCE WORK** Every 150 hours Every I 200 hours Every Every Type of operation 300 hours 600 hours Engine ٠ Engine oil topping up Change engine oil • Change engine oil filters • Change of blow-by filter • Replacing fuel filter ٠ • Adjustment of valve clearance • Change miscellaneous drive belts • Chassis and mechanical assemblies Change fuel pre-filter (if available) ٠

## **OFF-PLANE OPERATIONS**

#### Every year - Before winter

and possibly when a maintenance operation is carried out

Check the antifreeze percentage in the engine cooling water

#### Every two year

and possibly when a maintenance operation is carried out

Change engine coolant

**NOTE** Early air filter clogging is usually due to environmental conditions. For this reason, the filter should be changed if clogging is signalled by the related sensor, regardless of the prescriptions that shall be observed if no specific indications have been provided.
# **SECTION 4**

# Overhaul and technical specifications

		Page
GEN	NERAL CHARACTERISTICS	3
ASS	EMBLY CLEARANCE DATA	5
ENG	GINE OVERHAUL	
ENG	GINE REMOVAL AT THE BENCH	
REP	AIR OPERATIONS	12
CYL	INDER BLOCK	12
	Checks and measurements	12
CYL	INDER LINERS	13
	Replacing cylinder liners	15
	Removal	15
	Fitting and checking protrusion	15
CRA	ankshaft	16
	Measuring main journals and crank pins	17
PRE E	LIMINARY MEASUREMENT OF MAIN AND BIG	i 18
	Selecting the main and big end bearing shells .	19
	Replacing the timing control gear and the oil pump	25
	Checking main journal installation clearance	25
	Checking crankshaft end float	26
PIST	ON-CONNECTING ROD ASSEMBLY	27
	Removal	27
	Measuring the diameter of the pistons	28
	Conditions for correct gudgeon pin-piston coupling	28
	Piston rings	29

		Page
СО	NNECTING ROD	30
	Checking connecting rod alignment	32
	Mounting the connecting rod - piston assembly	33
	Mounting the piston rings	33
	Fitting the connecting rod-piston assembly into the piston liners	e 34
	Piston protrusion check	34
	Checking assembly clearance of big end pins	35
CYL	INDER HEAD	35
	Dismounting the valves	35
	Checking the planarity of the head on the cylinder block	35
VAL	VE	36
	Removing deposits and checking the valves	36
VAL	.ve guides	36
	Replacing of valve guides	37
	Replacing - Reaming the valve seats	37
REP	LACING INJECTOR HOLDER CASES	37
	Removal	37
	Checking protrusion of injectors	39

		Page
TIM	IING GEAR	40
	Camshaft drive	40
	Intermediate gear pin	40
	Idler gear	40
	Twin idler gear	40
	Replacing the bushings	40
	Camshaft	41
	Checking cam lift and pin alignment	41
	Bushes	42
	Use beater 99360505 to change bushings	43
	Removal	43
	Fitting	43
VAL	_VE SPRINGS	43
	Fitting the valves and oil seal ring	43
RO	CKER SHAFT	44
	Shaft	44
	Rocker	44
TIG	HTENING TORQUES	45

F2C CURSOR ENGINES

GENERAL CHARACTERISTICS					
	Туре		F2C		
<b>↑</b> <i>a</i>	Cycle		4-stroke Diesel engine		
	Fuel feed		Turbocharged		
	Injection	-	Direct		
	No. of cylinders		6 in line		
	Bore	mm	117		
	Stroke	mm	135		
	Total displacement	cm <sup>3</sup>	8710		

	Туре	F2C
	VALVE TIMING opens before T.D.C. A closes after B.D.C. B	17° 31°
	opens before B.D.C. D closes after T.D.C. C	48° 9°
	For timing check       K     mm       K     mm       Running     mm       X     mm       X     mm	- - 0.35 to 0.45 0.55 to 0.65
	FEED	Bosch Common Rail with CRIN2 injectors and high pressure pump CP3.3
	Nozzle type	DLLA 137
	Injection order	I - 4 - 2 - 6 - 3 - 5
bar U	Injection pressure bar Injector calibration bar	1800

#### **ASSEMBLY CLEARANCE DATA** F2C Type П CYLINDER BLOCK AND mm **CRANKMECHANISM COMPONENTS** ØI Bores for cylinder liners: 130.500 to 130.525 upper ØI 129.510 to 129.535 lower Cylinder liners: external diameter: 130.461 to 130.486 upper Ø2 129.475 to 129.500 lower 226,15 Ø2 length L 226.15 Cylinder liners crankcase bores Sp 0.014 to 0.064 upper 0.010 to 0.060 lower External diameter Ø2 A >Cylinder sleeve Ø3 inside diameter Ø3A\* 117.000 to 117.012 Х inside diameter ||7.0|0 to ||7.022 Ø3B\* Protrusion Х 0.035 to 0.065 \* Selection class Pistons: ØI measuring dimension Х 15 external diameter ØIA 116.894 to 116.906 116.904 to 116.916 external diameter ØIB Ø2 pin bore Ø2 52.010 to 52.016 Piston - cylinder sleeve 9P A\* 0.094 to 0.118 B\* 0.094 to 0.118 \* Selection class <Piston diameter Ø١ ŧΧ 0 0.873 to 1.117 Pistons protrusion Х Ø3 Gudgeon pin 51.994 to 52.000 Ø3 0.010 to 0.022 Gudgeon pin - pin housing

	T	F2C	
	Туре	mm	
	XI Piston ring grooves X2 X3	3,120 ÷ 3,140 3.120 to 3.140 2.550 to 2.570 4.020 to 4.040	
$\square \square \square \blacksquare \blacksquare$	Piston rings: trapezoidal sealSIlune sealS2milled scraper ring with slits and internal springS3	3.000 2.470 to 2.500 3.970 to 3.990	
	l Piston rings - grooves 2 3	- 0.050 to 0.100 0.030 to 0.070	
昌 >	Piston rings	-	
$\mathbf{b} = \begin{bmatrix} \mathbf{x} \\ \mathbf{x} \\ \mathbf{x} \\ \mathbf{x} \end{bmatrix}$	Piston ring end gap in cylinder liners XI X2 X3	0.3 to 0.4 0.60 to 0.75 0.35 to 0.65	
Ø ØI	Small end bush housing Ø	55.700 to 55.730	
	Big end bearing housing Ø2	85.987 to 86.013	
	Selection classes $\begin{cases} 2\\ 3 \end{cases}$	85.997 to 86.005 86.006 to 86.013	
	Small end bush diameter outside Ø4 inside Ø3 Big end bearing shell S Red Green Yellow •	55.780 to 55.820 52.015 to 52.030 1.994 to 2.002 2.002 to 2.010 2.010 to 2.018	
L C	Small end bush - housing	0.05 to 0.08	
	Piston pin - bush	0.015 to 0.036	
昌 >	Big end bearing	0.127 - 0.254 - 0.508	
	Connecting rod weight A A Class B C	g 3450 to 3470 3471 to 3490 3491 to 3510	

• Fitted in production only and not supplied as spares

			F2C
	Туре		mm
X	Measuring dimension	X	125
	Max. connecting rod axis misalignment tolerance		0.08
	Main journals - nominal - class - class - class Crankpins - nominal - class - class	ØI 2 3 Ø2 1 2	92.970 to 93.000 92.970 to 92.980 92.980 to 92.990 92.990 to 93.000 81.915 to 81.945 81.915 to 81.925 81.925 to 81.935
SI S2	- class Main bearing shells Red Green Yellow* Big end bearing shells Red Green Yellow*	3 SI S2	81.935 to 81.945 2.968 to 2.978 2.978 to 2.988 2.988 to 2.998 1.994 to 2.002 2.002 to 2.010 2.010 to 2.018
Ø 3	Main bearing housings - nominal - class - class - class - class	Ø3   2 3	99.000 to 99.030 99.000 to 99.009 99.010 to 99.019 99.020 to 99.030
	Bearing shells - main journals Bearing shells -		0.050 to 0.090
	big ends Main bearing shells Big end bearing shells		0.040 to 0.080 0.127 - 2.254 - 0.508 0.127 - 2.254 - 0.508
	Main journal, thrust bearing	XI	39.96 to 40.04
200 X2	Main bearing housing, thrust bearing	X2	38.94 to 38.99
×3	Thrust washer halves	X3	3.38 to 3.43
	Crankshaft end float		0.10 to 0.30
	Alignment $($ $\square$ I Ovalization $($ $\bigcirc$ I Taper I	- 2 - 2 - 2	- 0.04 -
* Fitted in production	only and not supplied as	s spai	res

	Туре	F2C
CYLINDER HEAD	- VALVE TRAIN	mm
	Valve guide housings in cylinder head Ø1	12.9800 to 12.997
	Valve guide Ø2 Ø3	8.023 to 8.038 13.012 to 13.025
	Valve guides - housings in the cylinder heads	0.015 to 0.045
	Valve guide	0.2 - 0.4
Ø 4	Valves:	
	⊂\$) Ø4 α	7.970 to 7.985 60° 30′ ± 7′ 30″
	$ \begin{array}{c}                                     $	7.970 to 7.985 45° <sup>+15</sup> -0
	Valve stem and its guide	0.040 to 0.070
	Valve seat in head ØI	41.985 to 42.020 40.985 to 41.020
Ø 2	Outside diameter of valve seat; angle of valve seat in cylinder head:	0'.
Α	$ \begin{array}{c} \swarrow \\ & & \\ & \\ & \\ & \\ & \\ & \\ & \\ & \\ &$	$42.060 \text{ to } 42.075$ $60^{\circ} - 30'$ $41.060 \text{ to } 41.075$ $45^{\circ} - 30'$
×	Recessing of valve	0.5 to 0.8 1.6 to 1.9
¢	Between valve seat and head	0.040 to 0.090

		F2C		
	Гуре	mm		
	Valve spring height:			
	free height H under a load of: N 460 ± 23 HIA N 460 ± 22 HIB N 740 ± 33 H2A N 731,4 ± 42 H2B	70.77 71.34 51 39		
×	Injector protrusion X	1.2 to 1.5		
	Camshaft bushing housing in the cylinder head: $I \Rightarrow 7 \qquad \emptyset$	69.000 to 69.030		
	Camshaft bearing journals: I ⇒ 7 Ø	64.924 to 64.080		
Ø	Outer diameter of camshaft bushings: Ø	69.090 to 69.130		
Ø	Inner diameter of camshaft bushings: Ø	65.080 to 65.116		
	Bushings and housings in the cylinder head	0.060 to 0.130		
	Bushings and bearing journals	0.100 to 0.192		
H H	Cam lift: ⊏∑	7.4034 8.2108		
	Rocker shaft Ø1	31.964 to 31.980		

	Туре	F2C	
		mm	
	Bushing housing in rocker arms		
		32.025 to 32.041	
Ø		32.025 to 32.041	
	Between bushings and housings		
		0.045 to 0.077	
		0.045 to 0.077	
TURBOCHARGER			
Туре		HX40	
End float		0.025 to 0.127	
Radial play		0.330 to 0.508	

## ENGINE OVERHAUL ENGINE REMOVAL AT THE BENCH

The following instructions are prescribed on the understanding that the engine has previously been placed on the rotating bench and that removal of all specific components of the equipment have been already removed as well. (See Section 3 of the manual herein).

The section illustrates therefore all the most important engine overhaul procedures.







The cylinder liners can be extracted and installed several times in different seats, if necessary.





||4040



0,035÷0,065

5

6

77812



35012

114041

3





## **CRANK PINS**

114045





\* Fitted in production only and not supplied as spares





## Selection of main half-bearings (rectified pins)

If the journals have been rectified, the procedure described cannot be applied.

In this case, make sure that the new diameter of the journals is as specified on the table and install the only half-bearing type required for this undersizing.

### Figure 28





#### Selection of connecting rod half-bearings (rectified pins) If pins have been rectified, the procedure described must be applied. In this case, (for each undersizing) determine the tolerance field the new big end pins belong to, and install the half-bearings identified according to the relative table. Figure 31 red/black = mm 2.057 to 2.065 green/black = -0.127 mm 2.065 to 2.073 green/black = mm 2.073 to 2.081 L 3 2 81.789 green/black green/black yellow/black 81.799 green/black yellow/black yellow/black 81.799 red/black green/black green/black 2 18 81.809 green/black green/black yellow/black 81.809 red/black red/black green/black 3 81.819 red/black green/black green/black





Using the hoist and hook 99360500 (1) mount the driving shaft (2).



Place bearing halves (1) on main journals (2).

Check the installation clearance between the main journals and the relative bearings as follows.

main journal supports as illustrated in Figure 18.



required, replace the half-bearings and repeat this check.











1. Coloured mark for identifying weight - 2. Coloured mark for identifying diameter grade - 3. Positioning stud visible from the front of the engine - 4. Progressive number for identifying connecting rod

W	EIGHT	DIAMETER		
	3450 g - 3470 g	Ø 85.987-85.996	Yellow	
GRADE A Yellow		Ø 85.997-86.005	Green	
1 Chow		Ø 86.006-86.013	Blue	
		Ø 85.987-85.996	Yellow	
GRADE B Green	3471 g - 3490 g	Ø 85.997-86.005	Green	
Green		Ø 86.006-86.013	Blue	
		Ø 85.987-85.996	Yellow	
GRADE C Blue	3491 g - 3510 g	Ø 85.997-86.005	Green	
Bide		Ø 86.006-86.013	Blue	







Check the torsion of the connecting rod (5) by comparing two points (**A** and **B**) of the pin (3) on the horizontal plane of the axis of the connecting rod.

Position the mount (1) of the dial gauge (2) so that this pre-loads by approx. 0.5 mm on the pin (3) at point **A** and zero the dial gauge (2). Shift the spindle (4) with the connecting rod (5) and compare any deviation on the opposite side **B** of the pin (3): the difference between **A** and **B** must be no greater than 0.08 mm.



Check the bending of the connecting rod (5) by comparing two points C and D of the pin (3) on the vertical plane of the axis of the connecting rod.

Position the vertical mount (1) of the dial gauge (2) so that this rests on the pin (3) at point C.

Swing the connecting rod backwards and forwards seeking the highest position of the pin and in this condition zero the dial gauge (2).

Shift the spindle (4) with the connecting rod (5) and repeat the check on the highest point on the opposite side D of the pin (3). The difference between point C and point D must be no greater than 0.08 mm.



TE The connecting rod screws can be reused as long as the diameter of the thread is not less than 11.4 mm.

## Mounting the piston rings



To fit the piston rings (1) on the piston (2) use the pliers 99360184 (3).

The rings need to be mounted with the word "TOP" (4) facing upwards. Direct the ring openings so they are staggered  $120^{\circ}$  apart.



## 540831 Checking assembly clearance of big end pins

To check the clearance proceed as follows:

connect the connecting rods to the relative main journals, place a length of calibrated wire on the latter.



Install the connecting rod caps (1) with half-bearings; tighten the connecting rod cap fixing screws (2) to 50 Nm (5 kgm) torque. By tool 99395216 (3), tighten the screws further at 90° angle.

Remove the caps and check the clearance by comparing the width of the calibrated wire with the scale calibration on the envelope containing the wire.

# 540610 CYLINDER HEAD

Before dismounting cylinder head, check cylinder head for hydraulic seal by proper tooling; in case of leaks not caused by cup plugs or threaded plugs, replace cylinder head.

**NOTE** In case of plugs dismounting/replacement, on mounting, apply sealant Loctite 270 on plugs.



**NOTE** Before dismounting cylinder head valves, number them in view of their remounting in the position observed on dismounting should they not have to be overhauled or replaced.

Intake valves are different form exhaust valves in that they have a notch placed at valve head centre.



Install and fix tool 99360264 (2) with bracket (4); tighten by lever (1) until cotters are removed (3); remove the tool (2) and the upper plate (5), the spring (6) and the lower plate (7).

Repeat the operation on all the valves.

Turn the cylinder head upside down and remove the valves (8).

# Checking the planarity of the head on the cylinder block



## 36159

The planarity (1) is checked using a ruler (2) and a thikness gauge (3). If deformations exist, surface the head using proper surface grinder; the maximum amount of material to be removed is 0.2 mm.

**NOTE** After leveling, make sure that valve sinking and injector protrusion are as described in the relative paragraph.



Remove carbon deposits using the metal brush supplied. Check that the valves show no signs of seizure or cracking.

Check the diameter of the valve stem using a micrometer (see Figure 66) and replace if necessary.



\* Values to be obtained after installing the valve guides

Check, by means of a micrometer, that valve stem diameters are as specified; if necessary, grind the valves seat with a grinder, removing the minimum quantity of material.



\* Values to be obtained after installing the guide valves

47509
#### **Replacing of valve guides**

Remove valve guides by means of tool 99360288.

Install by means of tool 99360288 equipped with part 99360294, which determines the exact installation position of valve guides into the cylinder heads; if they are not available, install the valve guides in the cylinder head so that they project out by mm 16.3 to 16.7 (Figure 66).

After installing the valve guides, smooth their holes with sleeker 99390310.

#### **Replacing - Reaming the valve seats**

To replace the valve seats, remove them using the appropriate tool.













Print P2D32C006E



performed in arrow direction, placing them as shown in figures.



If clearance exceeds 0.150 mm, replace bushes and, if necessary, the camshaft.





them, if the value measured exceeds the tolerance value. To take down and fit back the bushes, use the proper tool 99360487.

Figure 89



### 2 3) 2 3 87051 Lubricate the valve stem and insert the valves in the respective valve guides; fit the lower caps (1). Use tool 99360329 to fit the oil seal (2) on the valve guides (3) of the exhaust valves; then, to fit the valves, proceed as follows. NOTE Should valves not have been overhauled or replaced, remount them according to numbering performed on dismounting. Intake valves are different form exhaust valves in that they have a notch placed at valve head centre.



apply tool 99360264 (2) and block it with bracket (4); tighten the lever (1) until cotters are installed (3), remove tool (2).



The camshaft eccentric elements control the 12 valve rocker arms directly. Valve control rocker arms are fitted directly on rocker arm shaft. Rocker arms slide directly on cam profiles by rollers. The other end operates on a crosspiece laid directly on the two valve rods. A pad is placed between rocker arm adjustment screw and crosspiece. Two lube ducts are machined inside rocker a rms. Rocker arms shaft runs through the cylinder head; it must be removed to reach all units below.





#### TIGHTENING TORQUES

PART			TORQUE	
			Nm	kgm
Pipe union for piston cooling no	zzle	MI2XI.5	35 ± 2	3.5 ± 0.2
Heat exchanger retaining screws			63 ± 7	6.3 ± 0.7
Plug			125 ± 15	12.5 ± 1.5
Spacer and oil sump fastening sc	rews			
		MIO	41.5 ± 3.5	4.1 ± 0.3
Gearcase fastening screws to cylinder block:				
		MI0×1.25	41.5 ± 3.5	4.1 ± 0.3
		MI2×1.75	63 <b>±</b> 7	6.3 ± 0.7
		M8×1.25	23.5 ± 1.5	2.3 ± 1.5
Cylinder head fastening screw ♦				
First stage	pre-tightening		50	5
Second stage	pre-tightening		100	10
Third stage	angle closing		90	0
Fourth stage	angle closing		75	0
Rocker arm shaft fastening screw	/		104,5 ± 10,5	0,4 ±
			104.5 ± 10.5	0.4 ±
Locknut for rocker arm adjusting	screw 🔶		39 ± 5	3.9 ± 5
Electroinjector retaining bracket	screws 🔶			
		MIO	41.5 ± 3.5	4.1 ± 0.3
Shoulder plate fastening screws t	to head ♦		20 ± 2	2 ± 0.2
Engine support bracket fastening	screws to cylinder head		74 ± 8	7.4 ± 0.8
Gear fastening screws to camsha	lft •			
First stage	pre-tightening		25	2.5
Second stage	pre-tightening		45	0
Phonic wheel fastening screws to	distribution gear		8.5 ± 1.5	0.8 ± 0.1
Exhaust pipe fastening screws •				
pre-tightening			40 ± 5	4 ± 0.5
tightening			70 ± 5	7 ± 0.5
Connecting rod cap fastening sci	rews: ♦			
First stage	pre-tightening		50	5
Second stage	pre-tightening		90	0
Engine flywheel fastening screws	<b>*</b>	M18x1.5x72		
First stage	pre-tightening		120	12
Second stage	pre-tightening		90	
Flywheel pulley fastening screws	to crankshaft 🔶			
First stage	pre-tightening		70	7
Second stage	pre-tightening		50°	
Main journal retaining screws ♦				
First stage	pre-tightening		140	4
Second stage	pre-tightening		60° +	60°
<ul> <li>Lubricate with oil MOLYKO</li> </ul>	TE before assembly			
Lubricate with graphitized of	l before assembly			

PART		TOR	TORQUE	
		Nm	kgm	
Damper flywheel fasten	ing screws 🔶	5 ±  5	.5 <b>±</b>  .5	
Idler gear pin fastening :	screws 🔶			
First stage	pre-tightening	30	3	
Second stage	angle closing	9	0°	
Idle gear link rod fasten	ing screw	24.5 ± 2.5	2.4 ± 0.2	
Oil pump fastening scre	W	24.5 ± 2.5	2.4 ± 0.2	
Oil pump suction rose <sup>.</sup>	fastening screw	24.5 ± 2.5	2.4 ± 0.2	
Front cover fastening so	rew to cylinder block	19 ± 3	1.9 ± 0.3	
Control unit fastening s	crew to cylinder block	19 ± 3	1.9 ± 0.3	
Fuel filter support faster	ning screw to cylinder head $igle$	24.5 ± 2.5	2.4 ± 0.2	
Screw securing the eng	ine support to the wheelcase $igle$			
First stage	pre-tightening	100	10	
Second stage	angle closing	6	0°	
Turbo-compressor faste pre-tightening tightening	ening screws and nuts •	35 ± 5 46 ± 2	3.5 ± 0.5 4.6 ± 0.2	
Water pump fastening s	screw to cylinder block	24.5 ± 2.5	2.4 ± 0.2	
Pulley fastening screw t	o hub	55 ± 5	5.5 ± 0.5	
Rocker arm cover faste	ning screws	8.5 ± 1.5	0.8 ± 0.1	
Thermostat box fasteni	ng screws to cylinder head	24.5 ± 2.5	2.4 ± 0.2	
Automatic tightener fas	tening screws to cylinder block	45 ± 5	4.5 ± 0.5	
Fixed tightener fastening	g screws to cylinder block	105 ± 5	10.5 ± 0.5	
Fan support fastening so	crews to cylinder block	24.5 ± 2.5	2.4 ± 0.2	
Starter fastening screws		44 ± 4	4 ± 0.4	
Air heater on cylinder h	nead	30 ± 3	5 ± 0.5	
Hydraulic power steerir	ng pump gear fastening nut	105 ± 5	10.5 ± 0.5	
Air conditioner compre	ssor fastening screw to support	24.5 ± 2.5	2.4 ± 2.5	
Alternator support supe	erior fastening screw	71.5 ± 4.5	7.1 ± 0.4	
Alternator bracket faste	ning screw to cylinder block	24.5 ± 2.5	2.4 ± 0.2	
Water pipe unions		35	3.5	
Water temperature ser	sor	32.5 ± 2.5	3.2 ± 0.2	
<ul> <li>Lubricate with oil N</li> <li>Lubricate with grap</li> </ul>	10LYKOTE before assembly hitized oil before assembly			

PART		тс	ORQUE
		Nm	kgm
Flywheel rev sensor faster	ing screw	8 ± 4	
Camshaft rev sensor fastening screw		8 ± 4	
P.D.E solenoid connector	fastening screw		
Overboost pressure sense	or fastening screw	8 ± 2	
Absolute pressure sensor	fastening screw		
P.W.M. control valve faste	ning screw/nut	8 ± 2	
Fuel/coolant temperature	sensor	35	3.5
Coolant temperature indic	cator		
Filter clogging sensor		10	
Oil temperature switch		25 ±	
Oil pressure sensor		25 ±	
Electric wire fastening scre	2W	8 ± 2	
Gear fastening screws to a	camshaft •		
First stage	pre-tightening	40	
Second stage	pre-tightening		30°
Gear fastening screws to o	camshaft •		
First stage	pre-tightening	60	
Second stage	pre-tightening		45°
Heater fastening screw			
Gear fastening screws to o	camshaft •		
First stage	pre-tightening	25	
Second stage	pre-tightening	ç	)° ±  °
Gear fastening screws to o	camshaft •		
First stage	pre-tightening	25	
Second stage	pre-tightening	1.	5°±1°
Alternator positive retaining	ng nut	M8×1,25	
Starter terminal nut 30		MI0×1,5	
Starter terminal nut 50		M5×0,8	

SECTION 5	
	Page
TOOLS	3
EQUIPMENT MODIFIED FOR ADAPTATION TO CURSOR 9 ENGINE	11

# TOOLS TOOL NO. DESCRIPTION 99322230 Rotary telescopic stand (range 2000 daN, torque 375 daNm) 99331043 Tool to rotate engine flywheel (to be used with 99360325) 9934005 I Extractor for crankshaft front gasket 99340054 Extractor for crankshaft rear gasket 99342149 Extractor for injector-holder Tool to install the crankshaft front gasket 99346245

## TOOLS TOOL NO. DESCRIPTION 99346260 Percussion extractor Pliers for assembling and disassembling piston split rings 99360184 (105-106 mm) 99360264 Universal extractor for 5 to 70 mm internal components 99360288 Box wrench for block junction bolts to the underblock 99360292 Box wrench for block junction bolts to the underblock 99360294 Tool to fit back valve guide (to be used with 99360481)

### TOOLS TOOL NO. DESCRIPTION Compression tool for checking the protrusion of cylinder liners 99360334 $\sim$ (to be used with 99370415-99395603 and special plates) Cylinder liner compression plate 99360335 (to be used with 99360334-99360336) Cylinder liner compression plate 99360341 (to be used with 99360334-99360336) 0 99360500 Tool to lift crankshaft 99360505 Tool to lift crankshaft -Marine 99360558 Percussion extractor

### TOOLS TOOL NO. DESCRIPTION 99360585 Swing hoist for engine disassembly assembly <u> Natal</u> SK 4 A(O)Belt to insert piston in cylinder liner (60 - 125 mm) 99360605 99360612 Tool for positioning engine P.M.S. 99360613 Tool for timing of phonic wheel on timing gear 99360703 Tool to stop cylinder liners 99360706 Tool to extract cylinder liners (to be used with specific rings)

TOOLS	
TOOL NO.	DESCRIPTION
99360724	Ring (135 mm) (to be used with 99360706)
99361042	Tool to take down-fit engine valves (to be used with special plates)
99365054	Tool for injector holder heading
99368542	Tool to take down-fit engine valves (to be used with special plates)
99368554	Tool to take down-fit engine valves (to be used with special plates)
99368555	Tool to take down-fit engine valves (to be used with special plates)

TOOLS		
TOOL NO.		DESCRIPTION
99368556		Tool to take down-fit engine valves (to be used with special plates)
99368558		Tool to take down-fit engine valves (to be used with special plates)
99370415		Base supporting the dial gauge for checking cylinder liner protrusion (to be used with 99395603)
99389833	C	Base supporting the dial gauge for checking cylinder liner protrusion (to be used with 99395603)
99389834	A starting the start is a start in the start in th	Torque screwdriver (I-6 Nm) for calibrating the injector solenoid valve connector check nut
99390310		Valve guide sleeker













	Page
SAFETY PRESCRIPTIONS	

#### SAFETY PRESCRIPTIONS Standard safety prescriptions

Particular attention shall be drawn on some precautions that must be followed absolutely in a standard working area and whose non fulfillment will make any other measure useless or not sufficient to ensure safety to the personnel in-charge of maintenance.

Be informed and inform personnel as well of the laws in force regulating safety, providing information documentation available for consultation.

Keep working areas as clean as possible, ensuring adequate aeration.

Ensure that working areas are provided with emergency boxes, that must be clearly visible and always provided with adequate sanitary equipment.

Provide for adequate fire extinguishing means, properly indicated and always having free access. Their efficiency must be checked on regular basis and the personnel must be trained on intervention methods and priorities.

Organize and displace specific exit points to evacuate the areas in case of emergency, providing for adequate indications of the emergency exit lines.

Smoking in working areas subject to fire danger must be strictly prohibited.

Provide Warnings throughout adequate boards signaling danger, prohibitions and indications to ensure easy comprehension of the instructions even in case of emergency.

#### **Prevention of injury**

- Do not wear unsuitable cloths for work, with fluttering ends, nor jewels such as rings and chains when working close to engines and equipment in motion.
- Wear safety gloves and goggles when performing the following operations:
  - filling inhibitors or anti-frost
  - lubrication oil topping or replacement
  - utilization of compressed air or liquids under pressure (pressure allowed:  $\leq 2$  bar)
- Wear safety helmet when working close to hanging loads or equipment working at head height level.
- Always wear safety shoes when and cloths adhering to the body, better if provided with elastics at the ends.
- Use protection cream for hands.
- Change wet cloths as soon as possible
- □ In presence of current tension exceeding 48-60 V verify efficiency of earth and mass electrical connections. Ensure that hands and feet are dry and execute working operations utilizing isolating foot-boards. Do not carry out working operations if not trained for.
- Do not smoke nor light up flames close to batteries and to any fuel material.
- Put the dirty rags with oil, diesel fuel or solvents in anti-fire specially provided containers.

- Do not execute any intervention if not provided with necessary instructions.
- Do not use any tool or equipment for any different operation from the ones they've been designed and provided for: serious injury may occur.
- □ In case of test or calibration operations requiring engine running, ensure that the area is sufficiently aerated or utilize specific vacuum equipment to eliminate exhaust gas. Danger: poisoning and death.

#### **During maintenance**

- □ Never open filler cap of cooling circuit when the engine is hot. Operating pressure would provoke high temperature with serious danger and risk of burn. Wait unit the temperature decreases under 50°C.
- Never top up an overheated engine with cooler and utilize only appropriate liquids.
- Always operate when the engine is turned off: whether particular circumstances require maintenance intervention on running engine, be aware of all risks involved with such operation.
- Be equipped with adequate and safe containers for drainage operation of engine liquids and exhaust oil.
- Keep the engine clean from oil tangles, diesel fuel and or chemical solvents.
- Use of solvents or detergents during maintenance may originate toxic vapors. Always keep working areas aerated. Whenever necessary wear safety mask.
- Do not leave rags impregnated with flammable substances close to the engine.
- Upon engine start after maintenance, undertake proper preventing actions to stop air suction in case of runaway speed rate.
- Do not utilize fast screw-tightening tools.
- Never disconnect batteries when the engine is running.
- Disconnect batteries before any intervention on the electrical system.
- Disconnect batteries from system aboard to load them with the battery loader.
- After every intervention, verify that battery clamp polarity is correct and that the clamps are tight and safe from accidental short circuit and oxidation.
- Do not disconnect and connect electrical connections in presence of electrical feed.
- □ Before proceeding with pipelines disassembly (pneumatic, hydraulic, fuel pipes) verify presence of liquid or air under pressure. Take all necessary precautions bleeding and draining residual pressure or closing dump valves. Always wear adequate safety mask or goggles. Non fulfillment of these prescriptions may cause serious injury and poisoning.

#### 4 APPENDIX

Avoid incorrect tightening or out of couple. Danger: **Respect of the Environment** incorrect tightening may seriously damage engine's Respect of the Environment shall be of primary components, affecting engine's duration. importance: all necessary precautions to ensure Avoid priming from fuel tanks made out of copper alloys personnel's safety and health shall be adopted. and/or with ducts not being provided with filters. Be informed and inform the personnel as well of laws in Do not modify cable wires: their length shall not be force regulating use and exhaust of liquids and engine changed. exhaust oil. Provide for adequate board indications and organize specific training courses to ensure that Do not connect any user to the engine electrical personnel is fully aware of such law prescriptions and of equipment unless specifically approved by lveco. basic preventive safety measures. Do not modify fuel systems or hydraulic system unless Collect exhaust oils in adequate specially provided lveco specific approval has been released. Any containers with hermetic sealing ensuring that storage is unauthorized modification will compromise warranty made in specific, properly identified areas that shall be assistance and furthermore may affect engine correct aerated, far from heat sources and not exposed to fire working and duration. danger. For engines equipped with electronic gearbox: Handle the batteries with care, storing them in aerated Do not execute electric arc welding without having environment and within anti-acid containers. Warning: priory removed electronic gearbox. battery exhalation represent serious danger of intoxication and environment contamination. Remove electronic gearbox in case of any intervention requiring heating over 80°C temperature. Do not paint the components and the electronic connections. Do not vary or alter any data filed in the electronic gearbox driving the engine. Any manipulation or alteration of electronic components shall totally compromise engine assistance warranty and furthermore may affect engine correct working and duration.

#### Part 2 G-DRIVE CURSOR ENGINES

Section

I

2

General specifications

G-Drive Application

#### PREFACE TO USER'S GUIDELINE MANUAL

Section 1 describes engines F2C in their characteristics and general operation.

Section 2 is specific of use.

**NOTE** Part no. 2 is characterized by describing a particular industrial/agricultural application: G-Drive motors.

These engines are marketed as an assembly that is also equipped with the air/coolant and possibly air/air (intercooler) cooling device.

The description of this application gives the differences with the industrial application (given in the preceding Parts) and reference must be made to it for all repair and maintenance work.

#### UPDATING

Section	Description	Page	Date of revision

#### SECTION I

#### General specifications

	Page
CORRESPONDENCE BETWEEN TECHNICAL CODE AND COMMERCIAL CODE	3
LUBRICATION	4
COOLING	5
Description	5
Operation	5
FUEL FEED	6
TURBOCHARGING	7
# CORRESPONDENCE BETWEEN TECHNICAL CODE AND COMMERCIAL CODE

Technical Code	Commercial Code
F2CE9685A*E001	
F2CE0685B*E002	CORSOR 87 TE A



# COOLING

## Description

The engine cooling system is of the closed-circuit, forced circulation type. It consists mainly of the following components:

<u> </u>		
	expansion	tank
	expansion	coning

a heat exchanger to cool down lubrication oil;

a water pump with centrifugal system incorporated in the cylinder block;

🗋 fan;



a 2-way thermostat controlling the coolant circulation.

# Operation

The water pump is actuated by the crankshaft through a poli-V belt and sends coolant to the cylinder block, especially to the cylinder head (bigger quantity). When the coolant temperature reaches and overcomes the operating temperature, the thermostat is opened and from here the coolant flows into the radiator and is cooled down by the fan.



# SUPPLY

The Common Rail supply system is equipped with a special pump that maintains fuel at constant high pressure regardless from phase and cylinder under injection and accumulated in an common duct shared by all electric injectors.

Therefore, fuel at injection pressure, calculated by ECU, is always available at electric injection inlet.

When the solenoid value of an injector is energized by ECU, in related cylinder the injection of fuel taken directly from the rail takes place.

Figure 3





#### **SECTION 2 G-Drive** application Page F3B GENERAL CHARACTERISTICS ..... 3 F3B ASSEMBLY CLEARANCE DATA ..... 6 ENGINE CONNECTION AND DISCONNECTION FROM THE RADIATOR ..... 13 Removal ..... 13 13 Refitting ..... MAINTENANCE PLANNING ..... 15 MAINTENANCE PLANNING ..... 17 17 Inspection and/or maintenance interventions . 17 OPERATIONS OUTSIDE THE PLAN ..... 18 18 Daily checks Every year – Before winter ..... 18 18 Every two year ..... MAINTENANCE PROCEDURES ..... 19 Checks and controls ..... 19 PRINCIPLE ELECTRICAL DIAGRAM ..... 23 24 Function symbols for the control panel . . . . . 24 ENGINE INTERFACE BOX ..... 25 Description ..... 25 Connectors ..... 26 EDC 7 UC31 ELECTRONIC CONTROL UNIT 29 EDC control unit PIN-OUT 30

	Туре	F2CE9685A*E001
	Cycle	Diesel 4 strokes
	Feeding	Turbocharged
	Injection	Direct
	N. of cylinders	6 on-line
	Diameter mm	117
	Stroke mm	35
· + · + · + · + · · =	<b>-</b> Total displacement cm <sup>3</sup>	8710
0	Compression ratio	1:15.9 ± 0.8
	Europe market Max. output kW (HP) rpm	263 (358) 1500
	Max. torque Nm (kgm) rpm	1675 (170.7) 1500
	SUPERCHARGING	With intercooler
	Turbocharger type	HX 55
	LUBRICATION	Forced by gear pump, relief valve single action
bar	Oil pressure (warm engine)	On linter
	- idling bar - peak rpm bar	- -
	COOLING Water pump control Thermostat	Liquid Through belt
	- start of opening °C	85 ± 1.5
<b>DTE</b> Data, features provided by FF Furthermore, t	and performances are valid only if th T.	e setter fully complies with all the installation prescriptions

	Туре	F2CE0685B*E002
1 A	Cycle	Diesel 4 strokes
	Feeding	Turbocharged
	Injection	Direct
	N. of cylinders	6 on-line
	Diameter mm	117
	Stroke mm	135
	Total displacement cm <sup>3</sup>	8710
0	Compression ratio	1:15.9 ± 0.8
	USA market Max. output kW (HP) rpm	290 (401) 1800
	Max. torque Nm (kgm) rpm	1539 (156.9) 1800
	SUPERCHARGING	With intercooler
	Turbocharger type	HX 55
bar	LUBRICATION Oil pressure (warm engine)	Forced by gear pump, relief valve single action oil filter
	- idling bar - peak rpm bar	
	COOLING Water pump control Thermostat - start of opening °C	Liquid Through belt 85 ± 1.5
<b>NOTE</b> Data, features ar provided by FPT Furthermore, the turns based on v	nd performances are valid only e users assembled by the setter which the engine has been desig	if the setter fully complies with all the installation prescriptions shall always be in conformance to couple, power and number of med.

	Туре		F2C
	VALVE TIMING opens before T.D.C.	А	۱7°
	closes after B.D.C.	В	31°
	opens before B.D.C. closes after T.D.C.	D C	48° 9°
	For timing check X { Running X {	mm mm mm	- - 0.35 to 0.45 0.55 to 0.65
	FEED		Bosch Common Rail with CRIN2 injectors and high pressure pump CP3.3
Ļ	Nozzle type		DLLA 137
	Injection order		- 4 - 2 - 6 - 3 - 5
bar F	Injection pressure Injector calibration	bar bar	1800

ASSEMBLY CLEA	RANCE DATA	
	Туре	F2C
CYLINDER BLOCK	AND SM COMPONENTS	mm
	Bores for cylinder liners: upper Ø I lower	30.500 to  30.525  29.5 0 to  29.535
Ø2	Cylinder liners: external diameter: Ø2 lower length L	30.46  to   30.486   29.475 to   29.500 226,15 226   5
	Cylinder liners - crankcase bores upper lower	0.014 to 0.064 0.010 to 0.060
	External diameter Ø2	-
Ø3 * Selection class	Cylinder sleeve inside diameter Ø3A* inside diameter Ø3B* Protrusion X	7.000 to   7.0 2   7.0 0 to   7.022 0.035 to 0.065
	Pistons:measuring dimensionXexternal diameterØTAexternal diameterØTBpin boreØ2Piston - cylinder sleeve	15 116.894 to 116.906 116.904 to 116.916 52.010 to 52.016
	A* B*	0.094 to 0.118 0.094 to 0.118
	Piston diameter Ø1	-
	Pistons protrusion X	0.873 to 1.117
Ø3	Gudgeon pin Ø3	51.994 to 52.000
	Gudgeon pin - pin housing	0.010 to 0.022

		F2C
	Туре	F2C
		mm
	XI	3,120 ÷ 3,140 3,120 to 3,140
	Piston ring grooves X2	2.550 to 2.570
	X3	4.020 to 4.040
	Piston rings: trapezoidal seal SI	3.000
S I	lune seal S2	2.470 to 2.500
	milled scraper ring with slits and internal spring S3	3.970 to 3.990
	l Piston rings - grooves 2 3	- 0.050 to 0.100 0.030 to 0.070
<u> </u>	Piston rings	-
	Piston ring end gap in cylinder liners	
	XI	0.3 to 0.4
	X2 X3	0.60 to 0.75
	X	
Ø	Small end bush housing ØI	55.700 to 55.730
	Big end bearing housing Ø2	85.987 to 86.013
	Selection classes $\begin{cases} 1\\ 2\\ 3 \end{cases}$	85.987 to 85.996 85.997 to 86.005 86.006 to 86.013
Ø <b>4</b>	Small end bush diameter	
	outside Ø4	55.780 to 55.820
	inside 🗳 Ø3	52.015 to 52.030
	Big end bearing shell S	1 994 to 2 002
S S	Green Yellow ●	2.002 to 2.010 2.010 to 2.018
	Small end bush - housing	0.05 to 0.08
	Piston pin - bush	0.015 to 0.036
<u></u> 	Big end bearing	0.127 - 0.254 - 0.508
	Connecting rod weight A	g
	A	3450 to 3470
	Class B	3471 to 3490
	С	3491 to 3510

• Fitted in production only and not supplied as spares

		F2C
	Туре	mm
	Measuring dimension	٢ ١25
	Max. connecting rod axis misalignment tolerance —	0.08
	Main journals     Ø       - nominal     -       - class     -       - class     -       Crankpins     Ø       - nominal     -       - class     -       - class     -       Crankpins     Ø       - class     -       - class     - <td>I       92.970 to 93.000         I       92.970 to 92.980         2       92.980 to 92.990         3       92.990 to 93.000         2       81.915 to 81.945         I       81.915 to 81.925         2       81.925 to 81.935         3       81.935 to 81.945         I       2.968 to 2.978         2.978 to 2.988       2.988 to 2.998</td>	I       92.970 to 93.000         I       92.970 to 92.980         2       92.980 to 92.990         3       92.990 to 93.000         2       81.915 to 81.945         I       81.915 to 81.925         2       81.925 to 81.935         3       81.935 to 81.945         I       2.968 to 2.978         2.978 to 2.988       2.988 to 2.998
Ø 3	Big end bearing shells Si Red Green Yellow* Main bearing housings Ø - nominal - class - class	2 1.994 to 2.002 2.002 to 2.010 2.010 to 2.018 3 99,000 to 99.030 1 99,000 to 99.030 99,000 to 99.099 2 99,010 to 99.019
	- class Bearing shells - main journals Bearing shells -	3 99.020 to 99.030 0.050 to 0.090 0.040 to 0.080
	Main bearing shells Big end bearing shells Main journal,	0.127 - 2.254 - 0.508 0.127 - 2.254 - 0.508
	Main bearing housing, thrust bearing X	2 38.94 to 38.99
	Thrust washer halves X Crankshaft end float	3 3.38 to 3.43 0.10 to 0.30
	Alignment Ovalization Taper	2 - 2 0.04 2 -

Fitted in production only and not supplied as spares

	Туре	F2C
CYLINDER HEAD	- VALVE TRAIN	mm
	Valve guide housings in cylinder head Ø1	12.9800 to 12.997
	Valve guide        Ø2 Ø3	8.023 to 8.038   3.0 2 to   3.025
d d d d d d d d d d d d d d d d d d d	Valve guides - housings in the cylinder heads	0.015 to 0.045
>	Valve guide	0.2 - 0.4
Ø 4	Valves:	
		7.970 to 7.985 60° 30′ ± 7′ 30″
α	$\sum_{\alpha} \qquad \qquad$	/.9/0 to /.985 45° -0
	Valve stem and its guide	0.040 to 0.070
	Valve seat in head ØI ØI	41.985 to 42.020 40.985 to 41.020
Ø 2	Outside diameter of valve seat; angle of valve seat in cylinder head:	0'
		$42.060 \text{ to } 42.075$ $60^{\circ} - 30'$ $\overset{0}{-0.5'}$ $41.060 \text{ to } 41.075$
	$\alpha$	45° - 30'
××	Recessing of valve	0.5 to 0.8
<b>A</b> ^		1.0 to 1.7
d d d d d d d d d d d d d d d d d d d	Between valve seat and head	0.040 to 0.090
		·

	Туре	F2C
	.,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	mm
	Valve spring height:	A B
	free height H under a load of:	- 70.77
	N 460 ± 23 HIA N 460 ± 22 HIB	51
	N 740 ± 33 H2A N 731,4 ± 42 H2B	39
×	Injector protrusion X	I.2 to Ⅰ.5
	Camshaft bushing housing in the cylinder head: $I \Rightarrow 7 \qquad \emptyset$	69.000 to 69.030
	Camshaft bearing journals: I ⇒ 7 Ø	64.924 to 64.080
Ø	Outer diameter of camshaft bushings: Ø	69.090 to 69.130
Ø	Inner diameter of camshaft bushings: Ø	65.080 to 65.116
	Bushings and housings in the cylinder head	0.060 to 0.130
	Bushings and bearing journals	0.100 to 0.192
н	Cam lift: ⊏≳)	7.4034
		8.2108
	Rocker shaft Ø1	31.964 to 31.980

I.		
	Туре	F2C
	Type	mm
	Bushing housing in rocker arms	
		32.025 to 32.041
Ø		32.025 to 32.041
	Between bushings and housings	
Ś		0.045 to 0.077
ŕ		0.045 to 0.077
TURBOCHARGER		
Туре		HX55
. / F -		0.025 to 0.127
End float		0.025 to 0.127
		0.406 to 0.127
Kadial play		0.330 to 0.508



# Removal

Prepare a suitable container near the pipe coupling (12) to recover the coolant. Detach and remove the pipe couplings (12) and (7) operating the clamps.

Detach and remove from the engine and from the radiator the pipes (5) and (11) operating on their collars.

Remove the protection grilles (10) and the guard (8) of the fan operating on their fasteners.

Unscrew the engine side retaining nut of the fabric (6) so as to release it.

Suitably lock the radiator group (9), the detach it from the basement operating on the fasteners on both sides.

Detach the air filter from the engine (1) operating from collar (4) and the support (16) operating on the fasteners (15) after detaching the oil vapour hose (3) and the pipe coupling (4) from the turbocharger

Remove the screws which fasten the engine supports to the basement and detach the engine.

To access the engine belt, it is necessary to remove the protection guard (13), unscrewing the screws (14).



00

# Refitting

For the connection operation repeat the described operations for the disconnection on the contrary and apply the following instructions:

- to control the engine elastic supports and to replace them in case of deterioration ;
- i to control that the exhaust pipes are not deteriorated or are going to deteriorate; in this case you shall replace them;
- to clamp the screws and/or nuts to the described couple;
- to fill the cooling system with cooling liquid;
- to carry out bleeding operation from the fuel supply system as described in the suited paragraph.
- to control engine oil level;
- to carry out the tests and controls as described in the suited chapter.

# MAINTENANCE PLANNING

Base - June 2007

Print P2D32C006E

# MAINTENANCE PLANNING

## Recovery

To ensure optimised working conditions, in the following pages we are providing instructions for the overhaul control interventions, checks and setting operations that must be performed on the engine at due planned dates.

The frequency of the maintenance operations is just an indication since the use of the engine is the main characteristic to determine and evaluate replacements and checks.

It is not only allowed but recommended that the staff in charge of the maintenance should also carry out the necessary maintenance and controlling operations even if not being included in the ones listed here below but that may be suggested by common sense and by the specific conditions in which the engine is run.

# Inspection and/or maintenance interventions

Intervention type	Frequency (hours)
Engine	
Engine visual inspection	Daily
Check presence of water in fuel prefilter	Daily
Engine oil change	Every 600 hours
Engine oil filter change	Every 600 hours
Fuel prefilter change	Every 300 hours
Fuel filter change	Every 300 hours
Fuel Blow-by filter	Every 600 hours
Check condition of water pump/alternator control belt	Every   200 hours
Check-up of EDC system by diagnostics tool	-
Check valve lash and adjust, if required	Every 1200 hours
Dry air filter change and container cleaning	-

**NOTE** The maintenance operations are valid only if the setter fully complies with all the installation prescriptions provided by FPT.

# **OPERATIONS OUTSIDE THE PLAN**

## **Daily checks**

It is a good habit to execute, before engine start, a series of simple checks that might represent a valid warranty to avoid inconveniences, even serious, during engine running. Such checks are usually up to the operators and to the vehicle's drivers.

- Level controls and checks of any eventual leakage from the fuel, cooling and lubricating circuits.
- Notify the maintenance if any inconvenience is detected of if any filling is necessary.

After engine start and while engine is running, proceed with the following checks and controls:

- check presence of any eventual leakage from the fuel, cooling and lubricating circuits.
- Verify absence of noise or unusual rattle during engine working.
- Verify, using the vehicle devices, the prescribed pressure temperature and other parameters.
- Visual check of fumes (colour of exhaust emissions)
- Checking the coolant level.

**NOTE** Early air filter clogging is usually due to environmental conditions. For this reason, the filter should be changed if clogging is signalled by the related sensor, regardless of the prescriptions that shall be observed if no specific indications have been provided.

#### Every year - Before winter

and possibly when a maintenance operation is carried out

Check the antifreeze percentage in the engine cooling water

#### Every two year

and possibly when a maintenance operation is carried out

Change engine coolant

## MAINTENANCE PROCEDURES Checks and controls

#### Engine oil level check.

The check must be executed when the engine is disconnected and possibly cool.

The check can be made using the specially provided flexible rod.

Draw off the rod from its slot and check that the level is within the etched tags of minimum and maximum level.

Whether it should be difficult to make the evaluation, proceed cleaning the rod using a clean cloth with no rag grinding and put it back in its slot. Draw it off again and check the level.

In case the level results being close to the tag showing minimum level, provide filling lubrication of the engine's components.

To provide filling, operate through the upper top (1) or through the lateral top (2). During filling operation, the tops must be removed as well as the rod in order to make the oil flow easier".

Refill through upper tappet cover plug. During refill, remove dipstick for easier oil drain.



The engine oil is highly polluting and harmful. In case of contact with the skin, rinse well with water and detergent.

Adequately protect the skin and the eyes, operate in full compliance with safety regulations.

Disposal must be carried out properly, and in full compliance with the law and regulations in force.

## Check of fuel system

The check must be executed both when the engine disconnected and when it is running.

The check is made by observing the fuel pipes from the tank to the fuel pump and to the injectors.

## Cooling system check

The check must be executed both when the engine disconnected and when it is running.

Check the pipes from the engine to the radiator and vice versa; note any seepage and the state of the pipes especially near the coupling clamps.

Verify that the radiator is clean, the correct working of the fan flywheels, the presence of any leakage from the connectors, from the manifold and from the radiating unit.



Due to the high temperatures achieved by the system, do not operate immediately after the engine's disconnection, but wait for the time deemed necessary for the cooling.

Protect the eyes and the skin from any eventual high pressure jet of cooling liquid.

The density of the cooling liquid must be checked any how every year before winter season and be replaced in any case every two year.

**NOTE** In case of new filling, proceed bleeding system, through the bleeds on the engine.

If bleeding of the system is not carried out, serious inconvenience might be caused to the engine due to the presence of air pockets in the engine's head.

## Lubricating system check

The check must be executed both when the engine disconnected and when it is running.

Verify the presence of any oil leakage or blow-by from the head, from the engine pan of from the heat exchanger.



The engine oil is highly polluting and harmful. In case of contact with the skin, rinse well with water

and detergent. Adequately protect the skin and the eyes, operate in

full compliance with safety regulations.

Disposal must be carried out properly, and in full compliance with the law and regulations in force.

#### Check for any water in the fuel filter



The components of the system can be damaged very quickly in presence of water or impurity within the fuel.

Take prompt action on the filter to drain off the water in the fuel circuit.

Fuel filter is equipped with pump screw-valve to drain the water eventually mixed with fuel.

Place a container underneath the filter and slightly loosen the screw. Drain the water eventually contained in the filter's bottom.

Lock the screw (max 0.5 Nm locking couple) as soon as fuel starts bleeding.



Check the level through the dipsick until when the filling is next to the maximum level notch indicated on the dipsick.

### Engine oil filter change





Disconnect electric connector (2). Unlock prefilter (1) and change it. Before refitting a new cartridge, wet seal with fuel oil or engine oil. Lock cartridge by hand till in contact with support, then lock it by  $\frac{3}{4}$  of a rev. at predefined tightening torque.

At change, filter cartridge must not be prefilled to prevent circulating dirt that could damage injector/pump system components. Bleed air from fuel filter as described in previous pages.





Use tool 99360314 to remove fuel filter (1). Before fitting the new cartridge, wet seal with fuel oil or engine oil. Lock the new one by hand and carefully check that rubber seal and contact surface are clean and in perfect conditions. Lock cartridge by hand till contact with support and then lock it for  $\frac{3}{4}$  of a rev. at prescribed tightening torque. Bleed air from supply system as described in paragraph below:



Unlock screws (1) and remove cover (2). Remove the centrifugal filter (3) underneath and replace it.



Install blow-by body (1) with related seal and lock screws (2) at required torque.

Install cover (3) and lock screws (4) at required torque.



### Valve lash check a adjustment

For correct operation, follow instructions contained in related chapter in section 3 – Industrial Application.

## Change dry air filter and clean its container

Refit container cover, remove cartridge from air filter. Carefully clean container inside, insert new cartridge and refit cover.



Key to components	
RAT	Starter batteny 121/
M	Starter motor
G	Battony charger alternator
	Fuel filter besting resiston
	Fuel filter heating resistor
TRFC	Fuel filter heating thermostat
TPAC	VVater in the fuel filter transmitter
TBLA	Low engine water level transmitter
TPO	Engine oil pressure switch
TBPO	Low engine oil level pressure switch
TTA	Engine water temperature transmitter
TCE	No fuel transmitter (option)
TBLC	Float for fuel level
TS	Engine water heater thermostat
EDC	Engine electronic control unit
ΤΑΤΑ	High engine water temperature thermostat
SI	Control panel - engine interface box
<b>F</b>	
	on symbols for the control panel
	ENGINE WATER TEMPERATURE THERMOMETER
	LOW ENGINE OIL PRESSURE VISUAL WARNING
	ENGINE OIL PRESSURE GAUGE
	STARTING THE ENGINE (+50)
- <u>/</u>	NO BATTERY CHARGING VISUAL WARNING
	LOW ENGINE WATER LEVEL VISUAL WARNING
+15	CAPTIVE KEY POSITIVE (+15)
	WATER IN THE FUEL FILTER VISUAL WARNING
	HIGH ENGINE WATER TEMPERATURE VISUAL WARNING
	CAN LINE
	CONTROL PANEL POWER SUPPLY
Image: Constraint of the second secon	ENGINE PRE-HEATING
	FUEL LEVEL VISUAL WARNING
	NO FUEL VISUAL WARNING (OPTION)



## LIST OF COMPONENTS

K1. Power relay with key inserted (+15) - K2. Starting phase signal relay - K3. Starting relay - K4. Relay for pre-heating resistance enabling - JP1. Jumper to select frequency (jumper on 1-2= 60Hz - jumper on 2-3= 50Hz) - JP2. Jumper for operating mode selection (bond on 1-2= diagnosis - bond on 2-3= normal operation) - JP3. Jumper to select cold start signal connection (1-2= connected - 2-3= disconnected) - JP4. Jumper to select heat. function for cold starting (1-2= connected - 2-3= disconnected) - JP4. Jumper to select heat. function for cold starting (1-2= connected) - JP6. Not used - JP5. Jumper for Can Line selection (1-2= Can Line connected - 2-3= Can Line not connected) - JP6. Not used - JP8. Not used - BP1. Switch for blink-code signal request - LD1. LED signalling blink/code - F1. 10A fuse for starting engine - F2. 3A fuse for diagnostics - F3. 20A protection fuse for pre-heating resistance - F4. 30A fuse for electronic control unit - F5. 10A fuse for control panel - F6. 5A fuse for cut-in +15 ON ECU - F7. 20A protection fuse for fuel filter heater - F8. Not used - F9. Not used - J1. Connector for power connections - J2. Connector for interface with engine control unit - J3. Connector for interface with control panel - J7. Connector for interface with control panel - J9. Connector for interface with control panel.

107437



- 5 Spare
- 6 Spare

## **CONNECTOR J2** on engine – control panel interface box for EDC ECU connections

- + 15 from ignition key
- 2 I 2 jumper
- 3 Negative signal from oil low pressure pressure switch
- 4 Signal from water temperature sensor
- 5 Negative signal from water high temperature pressure switch
- 6 Signal from fuel zero level transmitter
- 7 Fuel low level signal
- 8 Supply of water presence in fuel sensor
- 9 Signal from water presence in fuel sensor
- 10 Ground of water presence in fuel sensor
- II Jumper with 37
- I 2 Jumper with 2
- 13 Positive +30
- 14 Positive +30
- 17 Supply of water low level sensor
- 18 Signal from water low level sensor
- 19 Ground of water low level sensor
- 20 No recharge from alternator signal
- 22 Ground for diagnosis lamp
- 23 Positive signal for diagnosis lamp
- 25 Torque limiting resistance
- 27 Line K diagnosis EDC
- 29 Negative signal from EDC system diagnostic switch
- 31 Signal from oil pressure sensor
- 32 Negative signal from water heater thermostat
- 33 Ground
- 37 Jumper with 11
- 40 Positive signal for excitation of contactor of fuel filter heater
- 41 Positive +30
- 42 Positive +30
- 46 Ground
- 47 Ground
- 48 Positive for cold start lamp
- 49 Positive for excitation of pre-heating contactor
- 50 Pre-heating contactor ground
- 53 Negative signal from EDC system diagnostic switch
- 54 Engine revs signal from EDC control unit
- 55 Line CAN L
- 56 Line CAN H

## NOTA Pins I and 2 of EDC ECU are connected to battery negative

CONNECTOR J3 inside the engine interface box for signals to control panel

l Free

- 2 From the engine water temperature transmitter for signal to thermometer on control panel
- 3 From the low engine oil pressure switch for visual warning on control panel
- 4 From engine oil pressure switch for signal to pressure gauge on control panel
- 5 Free
- 6 To the key switch (+50) on control panel
- 7 From the alternator for battery charging visual indicator on control panel
- 8 From the low engine water level transmitter for visual warning on control panel
- 9 +15
- 10 From the water in fuel filter transmitter for visual warning on control panel
- II Free
- 12 Free

CONNECTOR J7 inside the engine interface box for signals to control panel

- I From the engine coolant high temp. thermostat for visual signal on control panel
- 2 CAN line L to the control panel
- 3 Positive to power control panel
- 4 Negative to power control panel
- 5 CAN line H to the control panel
- 6 From the engine water heater thermostat to the control panel
- 7 From the fuel level transmitter for visual warning on control panel
- 8 From the no fuel transmitter (opt)

CONNECTOR J9 inside the engine interface box

- I Cold start signal (option) if jumper JP3 set on 1-2
- 2 Cold start signal (option) if jumper JP3 set on 1-2
- 3 Cold start heater relay (option) if jumper JP4 set on 1-2
- 4 Cold start heater relay (option) if jumper JP4 set on 1-2
- 5 Free
- 6 Free
- 7 Free
- 8 Free
- 9 Free
- 10 Free





Positive signal for excitation of contactor of fuel filter heater

Negative signal from EDC system diagnostic switch

+15 from ignition key

Positive for cold start lamp

Torque limiting resistance

Torque limiting resistance

Line K - diagnosis EDC

Pre-heating contactor ground

Jumper with 21

36

40

56

62

66 74

75

85

89

7731

5553

0021

5120

-

0094

0156

2298